


W60 Series ISO 5599-1 Valves



Thank You!

You have purchased a premium-quality ROSS® pneumatic valve. It is a stainless-steel spool and sleeve valve built to the highest standards. With care in its installation and maintenance you can expect it to have a long and economical service life. So before you go any further, please take a few minutes to look over the information in this document. Then, save it for future reference and for the useful service information it contains.



VALVE INSTALLATION

Please read and make sure you understand all installation instructions before proceeding with the installation.
Additional technical documentation is available for download at rosscontrols.com.

If you have any questions about installation or servicing your valve, please contact ROSS or your authorized ROSS distributor, see contact information listed at the back of this document, or visit rosscontrols.com to find your distributor.

Pneumatic equipment should be installed only by persons trained and experienced in such installation.


Air Lines: Before installing a valve in a new or an existing system, the air lines must be blown clean of all contaminants. It is recommended that an air filter be installed in the inlet line close to the valve.

Valve Inlet (Port 1): Be sure that the supply line is of adequate size and does not restrict the air supply because of a crimp in the line, sharp bends, or a clogged filter element.

Valve Outlets (Ports 2 & 4): For faster pressurizing and exhausting of the mechanism being operated by the valve, locate the valve as close as possible to the mechanism. The lines must be of adequate size and be free of crimps and sharp bends.

Valve Exhausts (Ports 3 & 5): To reduce exhaust noise use an efficient silencer. ROSS silencers reduce impact noise by as much as 25 dB, and produce little back pressure.

Electrical Supply: The voltage and hertz ratings for solenoid pilot-operated valves are printed on the side of each solenoid. It is important that the electrical supply used to power the valve is equal to these ratings to avoid possible solenoid burnout. The electrical connection for such valves is achieved by means of a connector whose connections correspond to the prongs pictured in the sketch of a typical solenoid pilot.



If power is supplied by a transformer it must be capable of handling the inrush current without significant voltage drop. See *Valve Specifications* on page 2 for information on inrush current.

Operating Pressures and Temperatures: Allowable ranges for pressure and temperatures are given in the *Valve Specifications* on page 2. Exceeding the values shown can shorten valve life.

Pilot Supply:

Pressure Control: For valves with single remote pressure control, connect the control line to port 14 in the sub-base or manifold. For valves with double remote pressure control, connect the control lines to both ports 12 and 14 in the base. See *Valve Specifications* on page 2 for required pressures.

Solenoid Control: Pressure for the pilot valves is supplied from the inlet port. Be sure that port 14 in the base is plugged or pilot air will escape. If the valve must operate with an inlet pressure less than the required pilot pressure (see *Valve Specifications* on page 2), an external pilot supply of sufficient pressure must be provided. Connect the external pilot supply to port 14 in the base.

Vacuum or Non-Air Service: Such applications require an external pilot supply for solenoid valves. Connect to port 14 in the base.

Pipe Installation: To install pipe in valve or base ports, engage pipe one turn, apply pipe thread sealant (tape not recommended), and tighten pipe. This procedure will prevent sealant from entering and contaminating the valve.

VALVE MAINTENANCE

Supply Clean Air: Foreign material lodging in valves is a major cause of breakdowns. The use of an air filter located as close to the valve as possible is strongly recommended. The filter bowl should be drained regularly. If the filter's location makes manual draining difficult, the filter should be equipped with an automatic drain.

Check Lubricator Supply Rate: A lubricator should put atomized oil into the air line in direct proportion to the rate of air flow. Excessive air line lubrication can cause puddling in the valve and lead to malfunctions. For most applications an oil flow rate in the lubricator of one drop per minute of air flow is adequate. (Note that your ROSS valve does not itself require air line lubrication.)

Compatible Lubricants: Although this valve does not require air line lubrication, it may be used with lubricated air being supplied to other mechanisms. Some oils contain additives that can harm seals or other valve components and thereby cause the valve to malfunction. The best oils to use are those specifically compounded for air line lubricator service.

Cleaning Valve: If the air supplied to the valve has not been well filtered, the interior of the valve may accumulate dirt and varnish which can affect the valve's performance. To clean the valve use a solvent which will dry without leaving a residue. This is especially important for the spool-and-sleeve assembly.

Do not use a chlorinated solvent or abrasive materials which can damage seals or do permanent damage to metal parts.

To reassemble the spool and sleeve put one drop of Anderol 735 (or equivalent lubricant) on each spool land. Insert the spool into the sleeve and rotate it several times to ensure even distribution of the lubricant. If the valve is used in a non-lubricated application, do not use a lubricant for reassembly which can dry out and leave a residue. Dry assembly of the spool and sleeve is preferable. Each spool and sleeve is a matched set, so care must be taken not to reverse the position of the spool in the sleeve.

Before inserting the spool-and-sleeve into the valve body, very lightly lubricate the O-rings with a lubricant compounded for use on Buna-N seals. *Do not use Anderol; it causes the O-rings to deteriorate.*

Electrical Contacts: In the external electrical circuits associated with the valve solenoids, keep all switches or relay contacts in good condition to avoid solenoid malfunctions.

Replace Worn Components: After long usage the spool and sleeve may show signs of wear, as indicated by excessive air leakage between ports. The valve can be completely reconditioned with the use of a ROSS valve body service kit. See page 3 for information about such kits.

VALVE SPECIFICATIONS

Construction Design	Spool and Sleeve
Mounting Type	Base
Flow Media	Filtered air
Construction Material	Valve Body: Bar Stock Aluminum Spool: Stainless Steel Seals: Buna-N

Solenoids	Rated for continuous duty
Voltage	24 volts DC; 110-120 volts AC, 50/60 Hz
Power Consumption (each solenoid)	6 watts on DC; 11 VA inrush, 8.5 VA holding on 50 or 60 Hz
Enclosure Rating	IP65, IEC 60529

Electrical Connections	EN 175301-803 Form A connector
------------------------	--------------------------------

Temperature	Ambient: 40° to 120°F (4 to 50°C)
	Media: 40° to 175°F (4° to 80°C)
	<i>For other temperature ranges, consult ROSS.</i>

Pilot Supply	Internal or External; Selected automatically
--------------	--


Operating Pressure	Vacuum to 150 psig (10 bar)
	Pilot Supply - External: ISO Size 1: Minimum 30 psig (2 bar) ISO Size 2 & 3: Minimum 15 psig (1 bar)
	<i>When external pilot supply, pressure must be equal to or greater than inlet pressure.</i>

Manual Override	Flush; Metal, non-locking
-----------------	---------------------------

Pressure Controlled Valves	
Temperature	Ambient/Media: 40° to 175°F (4° to 80°C)
	<i>For other temperature ranges, consult ROSS.</i>
Operating Pressure	Vacuum to 150 psig (10 bar)
	Pilot Supply - External: ISO Size 1: Minimum 30 psig (2 bar) ISO Size 2 & 3: Minimum 15 psig (1 bar)
	<i>Pilot supply pressure must be equal to or greater than inlet pressure.</i>
Solenoid Pilot Controlled Valves	

IMPORTANT NOTE: Please read carefully and thoroughly all the **WARNINGS** and **CAUTIONS** on page 4.

Typical cross section of a ROSS W60 Series spool and sleeve valve body, spring return model shown.



VALVE SERVICE

ROSS would be happy to service this valve for you at its factory repair center. If you purchased your valve from ROSS please contact ROSS customer service, if you purchased your valve thru an authorized ROSS distributor please contact the distributor for return instructions.

However, if you choose to service this valve yourself, it is strongly recommended that you visit our website at rosscontrols.com for available downloadable technical documentation.

Listed below are the parts and service kits most likely to be needed if your valve requires service.

Valve Body Service Kits: These kits contain all parts needed for a complete reconditioning of a valve body. Included are a spool and sleeve assembly, all required gaskets and seals, detent assemblies for valves requiring them, and instructions for use.

Valve-to-Base Gasket: If your valve is removed from its base for any reason, a new valve-to-base gasket must be used to ensure a leak-free seal. (This gasket is included as a part of all valve body service kits.)

Solenoid Coils: Replacement coils for solenoid controlled valves can be ordered by part number listed in the table below.

Complete Solenoid Pilot Assemblies: These assemblies consist of new pilot valve mechanisms and a new solenoid coil, ready to bolt in position on the valve.

Valve Model Number	Valve Body Service Kit	Valve-to-Base Gasket
W6056B2411	1020K77	617B11
W6056B2417	831K77	617B11
W6056B3411	832K77	618B11
W6056B3417	916K77	618B11
W6056B4411	833K77	619B11
W6056B4417	917K77	619B11
W6057B2411	837K77	617B11
W6057B2417	838K77	617B11
W6057B3411	839K77	618B11
W6057B3417	840K77	618B11
W6057B4411	841K77	619B11
W6057B4417	842K77	619B11
W6076B2401	1020K77	617B11
W6076B2407	831K77	617B11
W6076B3401	832K77	618B11
W6076B3407	916K77	618B11
W6076B4401	833K77	619B11
W6076B4407	917K77	619B11
W6077B2401	837K77	617B11
W6077B2407	838K77	617B11
W6077B3401	839K77	618B11
W6077B3407	840K77	618B11
W6077B4401	841K77	619B11
W6077B4407	842K77	619B11

Voltage	Complete Solenoid Pilot Assemblies	Replacement Solenoid Coils
	Part Number	Part Number
24 volts DC 48 volts AC	851C79165	306K33165
110-120 volts AC 48 volts DC	851C79166	306K33166
210-220 volts AC 110 volts DC	851C79167	306K33167

Electrical Connector	Electrical Connector Type	Cord Length meters (feet)	Cord Diameter	Electrical Connector Model Number		
				Without Light	Lighted Connector*	
					24 Volts DC	120 Volts AC
EN 175301-803 Form A	Prewired Connector (18 gauge)	2 (6½)	6-mm	721K77	720K77-W	720K77-Z
	Prewired Connector (18 gauge)	2 (6½)	10-mm	371K77	383K77-W	383K77-Z
	Connector for threaded conduit (1/2 inch electrical conduit fittings)	–	–	723K77	724K77-W	724K77-Z
	Connector Only	–	–	937K87	936K87-W	936K87-Z

*Lights in connectors with a translucent housing can be used as indicator lights to show when solenoids are energized.

CAUTIONS And WARNINGS



PRE-INSTALLATION or SERVICE

1. Before servicing a valve or other pneumatic component, be sure that all sources of energy are turned off, the entire pneumatic system is shut off and exhausted, and all power sources are locked out (ref: OSHA 1910.147, EN 1037).
2. All ROSS® products, including service kits and parts, should be installed and/or serviced only by persons having training and experience with pneumatic equipment. Because any installation can be tampered with or need servicing after installation, persons responsible for the safety of others or the care of equipment must check every installation on a regular basis and perform all necessary maintenance.
3. All applicable instructions should be read and complied with before using any fluid power system in order to prevent harm to persons or equipment. In addition, overhauled or serviced valves must be functionally tested prior to installation and use. If you have any questions, call your nearest ROSS location listed in the table below.
4. Each ROSS product should be used within its specification limits. In addition, use only ROSS parts to repair ROSS products.

WARNINGS: Failure to follow these directions can adversely affect the performance of the product or result in the potential for human injury or damage to property.

FILTRATION and LUBRICATION

5. Dirt, scale, moisture, etc. are present in virtually every air system. Although some valves are more tolerant of these contaminants than others, best performance will be realized if a filter is installed to clean the air supply, thus preventing contaminants from interfering with the proper performance of the equipment. ROSS recommends a filter with a 5-micron rating for normal applications.
6. All standard ROSS filters and lubricators with polycarbonate plastic bowls are designed for compressed air applications only. Do not fail to use the metal bowl guard, where provided, to minimize danger from high pressure fragmentation in the event of bowl failure. Do not expose these products to certain fluids, such as alcohol or liquefied petroleum gas, as they can cause bowls to rupture, creating a combustible condition, hazardous leakage, and the potential for human injury or damage to property. Immediately replace a crazed, cracked, or deteriorated bowl. When bowl gets dirty, replace it or wipe it with a clean dry cloth.

7. Only use lubricants which are compatible with materials used in the valves and other components in the system. Normally, compatible lubricants are petroleum based oils with oxidation inhibitors, an aniline point between 180°F (82°C) and 220°F (104°C), and an ISO 32, or lighter, viscosity. Avoid oils with phosphate type additives which can harm polyurethane components, potentially leading to valve failure which risks human injury, and/or damage to property.

AVOID INTAKE/EXHAUST RESTRICTION

8. Do not restrict the air flow in the supply line. To do so could reduce the pressure of the supply air below the minimum requirements for the valve and thereby cause erratic action.
9. Do not restrict a valve's exhaust port as this can adversely affect its operation. Exhaust silencers must be resistant to clogging and must have flow capacities at least as great as the exhaust capacities of the valves. Contamination of the silencer can result in reduced flow and increased back pressure.

WARNINGS:

ROSS expressly disclaims all warranties and responsibility for any unsatisfactory performance or injuries caused by the use of the wrong type, wrong size, or an inadequately maintained silencer installed with a ROSS product.

POWER PRESSES

10. Mechanical power presses and other potentially hazardous machinery using a pneumatically controlled clutch and brake mechanism must use a press control double valve with a monitoring device. A double valve without a self-contained monitoring device should be used only in conjunction with a control system which assures monitoring of the valve. All double valve installations involving hazardous applications should incorporate a monitoring system which inhibits further operation of the valve and machine in the event of a failure within the valve mechanism.

ENERGY ISOLATION/EMERGENCY STOP

11. Per specifications and regulations, ROSS L-O-X® valves and L-O-X® valves with EEZ-ON® operation are defined as energy isolation devices, NOT AS EMERGENCY STOP DEVICES.

STANDARD WARRANTY

All products sold by ROSS CONTROLS are warranted for a one-year period [with the exception of all Filters, Regulators and Lubricators ("FRLs") which are warranted for a period of seven years] from the date of purchase to be free of defects in material and workmanship. ROSS' obligation

under this warranty is limited to repair or replacement of the product or refund of the purchase price paid solely at the discretion of ROSS and provided such product is returned to ROSS freight prepaid and upon examination by ROSS is found to be defective. This warranty becomes void in the event that product has been subject to misuse, misapplication, improper maintenance, modification or tampering.

THE WARRANTY EXPRESSED ABOVE IS IN LIEU OF AND EXCLUSIVE OF ALL OTHER WARRANTIES AND ROSS EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES EITHER EXPRESSED OR IMPLIED WITH RESPECT TO MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ROSS MAKES NO WARRANTY WITH RESPECT TO ITS PRODUCTS MEETING THE PROVISIONS OF ANY GOVERNMENTAL OCCUPATIONAL SAFETY AND/OR HEALTH LAWS OR REGULATIONS. IN NO EVENT IS ROSS LIABLE TO PURCHASER, USER, THEIR EMPLOYEES OR OTHERS FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES WHICH MAY RESULT FROM A BREACH OF THE WARRANTY DESCRIBED ABOVE OR THE USE OR MISUSE OF THE PRODUCTS. NO STATEMENT OF ANY REPRESENTATIVE OR EMPLOYEE OF ROSS MAY EXTEND THE LIABILITY OF ROSS AS SET FORTH HEREIN.

ROSS CONTROLS	USA	Tel: 1-248-764-1800	www.rosscontrols.com
ROSS EUROPA GmbH	Germany	Tel: 49-6103-7597-100	www.rosseuropa.com
ROSS ASIA K.K.	Japan	Tel: 81-42-778-7251	www.rossasia.co.jp
ROSS UK Ltd.	UK	Tel: 44-1543-671495	www.rossuk.co.uk
ROSS SOUTH AMERICA Ltda.	Brazil	Tel: 55-11-4335-2200	www.rosscontrols.com.br
ROSS CONTROLS INDIA Pvt. Ltd.	India	Tel: 91-44-2624-9040	www.rosscontrols.com
ROSS CONTROLS (CHINA) Ltd.	China	Tel: 86-21-6915-7961	www.rosscontrolschina.com
ROSS FRANCE S.A.S.	France	Tel: 33-1-49-45-65-65	www.rossfrance.com
ROSS CANADA (5077170 CANADA INC. AN INDEPENDENT REPRESENTATIVE)	Canada	Tel: 1-416-251-ROSS (7677)	www.rosscanada.com