

FLOW CONTROL VALVES 19 & 11 SERIES

PRODUCT CATALOG






Flow Control Valves 19 & 11 Series Product Overview

Flow Control Function

Flow control valves provide high air flow rates into a cylinder, and precisely controlled flow rates out of the cylinder. The adjustable flow can range from near zero to full flow.



Illustration examples.



Selecting flow control valves with sufficient flow capacity is important so that they do not become the limiting factor in the cylinder control system. Full flow capacity should match that of the control valve to keep cylinder motion smooth and predictable in both directions.

| VALVE FEATURES | | | | | |
|--------------------|---|--|--|--|--|
| Poppet Design | Dirt-tolerant poppet design; available in alternate materials for extreme temperature applications | | | | |
| High Flow | High flow capacity in free-flow direction (port 1 to 2), same high flow available in reverse direction | | | | |
| Visible Indication | Low-Profile High-Capacity valves – Brass stem gives visible indication of flow rate in controlled direction (port 2 to 1) | | | | |
| Positive Locking | Low-Profile High-Capacity valves – Prevents change of adjustment knob due to vibration or tampering | | | | |
| Adjustable Flow | Knob hand or screwdriver slot adjustment to control flow | | | | |

Specifications



| | | STAND | ARD SPECIFICATIONS | | |
|--------------|---------------------|--|------------------------------------|--|--|
| | Function | | 2-Way Valve | | |
| | Construction Design | | Poppet | | |
| | Actuation | | Pneumatic | | |
| | | | Low-Profile | | |
| | | Time | High-Capacity | Inline | |
| | | Туре | Low-Profile High-Capacity | | |
| GENERAL | Mounting | | Right-Angle | Screws directly into cylinder port | |
| | Widunting | | Low-Profile | Any, preferably vertical | |
| | | Orientation | High-Capacity | Inline, Offset | |
| | | Onemation | Low-Profile High-Capacity | Tillille, Oliset | |
| | | | Right-Angle | Inlet port can be swiveled 360° for optimum placement | |
| | Connection | | | Threaded; G, NPT | |
| | Minimum Operation F | requency | | Once per month, to ensure proper function | |
| | | | Ambient | | |
| | | Low-Profile | Media | 41° to 140°F (5° to 60°C) | |
| | Temperature | High-Capacity Low-Profile High-Capacity | Ambient | | |
| | | | Media | -40° to 175°F (-40° to 80°C) | |
| | | | For temperatures below 40° of ice. | F (4°C) air must be free of water vapor to prevent formation | |
| | | | For temperatures below -40 | °F (-40°C), consult ROSS. | |
| OPERATING | | | Ambient | 400 1 47505 (40 1 0000) | |
| CONDITIONS | | Right-Angle | Media | 40° to 175°F (4° to 80°C) | |
| | Flow Media | 1 | Filtered air | | |
| | Operating Pressure | Low-Profile | Supply Pressure | 217 psi (14.9 bar) | |
| | | Low-Proffie | Maximum Pressure | 150 psi (10.3 bar) | |
| | | High-Capacity | | | |
| | | Low-Profile High-Capacity | | 5 to 150 psig (0.3 to 10 bar) | |
| | | Right-Angle | | | |
| | | Low-Profile | | | |
| CONSTRUCTION | Valve Body | High-Capacity | | Cast Aluminum | |
| | | Low-Profile High-Capacity | | 1 | |
| | | Right-Angle | | Nickel-plated brass body, black anodized aluminum swive | |
| MATERIAL | Poppet | 1 | Acetal and Stainless Steel | | |
| | Spring | Right-Angle | | Stainless Steel | |
| | Seals | J 9. | Buna-N | | |
| | | | | | |

IMPORTANT NOTE: Please read carefully and thoroughly all of the CAUTIONS, WARNINGS on the inside back cover.


| PRODUCT CREDENTIALS | | | | | |
|----------------------------|---|--|--|--|--|
| EAC Conformity Declaration | Canadian Registration Number (CRN) | | | | |
| EAC | Available for appropriately tested valves | | | | |


Ordering Information


| FLOW CONTROL VALVES 2-Way Valve | | | | | | | | 2-Way Valves |
|---------------------------------|-------------------------|--------|---------------|-------|------------|---------------------|----------------|--------------|
| Valve Style | | | Size | | Valve Mod | Flow C _v | Weight Ib (kg) | |
| | | Port 1 | Port 1 Port 2 | | G Thread | | | NPT Thread |
| | with Slot | 1/8 | 1/8 | 1/8 | D1968F1004 | 1968F1004 | 0.5 | 0.1 (0.1) |
| | Adjustment | 1/4 | 1/4 | 1/4 | D1968F2004 | 1968F2004 | 0.5 | 0.1 (0.1) |
| Low-Profile | | 1/4 | 1/4 | 3/8 | D1968F2007 | 1968F2007 | 2.3 | 0.4 (0.2) |
| | with Knob Adjustment | 3/8 | 3/8 | 3/8 | D1968F3007 | 1968F3007 | 2.3 | 0.4 (0.2) |
| | 714,404 | 1/2 | 1/2 | 3/8 | D1968F4007 | 1968F4007 | 2.3 | 0.4 (0.2) |
| | | 1/4 | 1/4 | 3/8 | D1968B2007 | 1968B2007 | 2.3 | 0.5 (0.2) |
| | | 3/8 | 3/8 | 3/8 | D1968B3007 | 1968B3007 | 2.6 | 0.5 (0.2) |
| | | 1/2 | 1/2 | 3/8 | D1968B4017 | 1968B4017 | 2.6 | 0.5 (0.2) |
| | | 1/2 | 1/2 | 3/4 | D1968B4007 | 1968B4007 | 7.5 | 0.8 (0.4) |
| | | 3/4 | 3/4 | 3/4 | D1968B5007 | 1968B5007 | 8.3 | 0.8 (0.4) |
| High Consoits | | 1 | 1 | 3/4 | D1968B6017 | 1968B6017 | 8.3 | 0.8 (0.4) |
| High-Capacity | | 1 | 1 | 1-1/4 | D1968B6007 | 1968B6007 | 17 | 2.2 (1.0) |
| | | 1-1/4 | 1-1/4 | 1-1/4 | D1968B7007 | 1968B7007 | 22 | 2.2 (1.0) |
| | | 1-1/2 | 1-1/2 | 1-1/4 | D1968B8017 | 1968B8017 | 22 | 2.2 (1.0) |
| | | 1-1/2 | 1-1/2 | 2 | D1968B8007 | 1968B8007 | 50 | 4.3 (1.9) |
| | | 2 | 2 | 2 | D1968B9007 | 1968B9007 | 50 | 4.3 (1.9) |
| | | 2-1/2 | 2-1/2 | 2 | D1968B9017 | 1968B9017 | 50 | 4.3 (1.9) |
| | | 1/2 | 1/2 | 3/4 | D1968E4007 | 1968E4007 | 7.5 | 0.8 (0.4) |
| Low-Profile High-Capacity | | 3/4 | 3/4 | 3/4 | D1968E5007 | 1968E5007 | 8.3 | 0.8 (0.4) |
| LOW-FIUILE HI | yn-capacity | 1 | 1 | 1-1/4 | D1968E6007 | 1968E6007 | 17 | 2.1 (1.0) |
| | | 1-1/2 | 1-1/2 | 1-1/4 | D1968E7007 | 1968E7007 | 22 | 2.1 (1.0) |


| Valve Style | | 0 | Size | | Valve Model Number | | Flow C _v | Weight | |
|--|-------------------------|-------------------|--------|--------|--------------------|-------------|---------------------|--------|-------------|
| | | Connection | Port 1 | Port 2 | Body | G Thread | NPT Thread | 1-2 | lb (kg) |
| | | | 1/8 | 1/8 | 1/4 | D1968A1008 | 1968A1008 | 0.3 | 0.06 (0.03) |
| | | Threaded | 1/4 | 1/4 | 1/4 | D1968A2008 | 1968A2008 | 0.6 | 0.12 (0.05) |
| | | Inlet | 3/8 | 3/8 | 3/8 | D1968A3008 | 1968A3008 | 1.9 | 0.20 (0.09) |
| | with Slot | | 1/2 | 1/2 | 3/8 | D1968A4008 | 1968A4008 | 2.8 | 0.34 (0.15) |
| | Adjustment | | 1/8 | 1/8 | 1/4 | - | 1968A1108# | 0.3 | 0.06 (0.03) |
| | | Tuba Finina | 1/4 | 1/4 | 1/4 | - | 1968A2108 | 0.6 | 0.12 (0.05) |
| Pick Acces | | Tube Fitting | 3/8 | 3/8 | 3/8 | D1968A3108 | 1968A3108 | 1.9 | 0.20 (0.09) |
| | | | 1/2 | 1/2 | 3/8 | - | _ | 2.8 | 0.34 (0.15) |
| Right-Angle | with Knob Adjustment | | 1/8 | 1/8 | 1/4 | - | 1968A1008 | 0.3 | 0.08 (0.04) |
| | | Threaded Inlet | 1/4 | 1/4 | 1/4 | D1968A2018 | 1968A2018 | 0.6 | 0.14 (0.06) |
| | | | 3/8 | 3/8 | 3/8 | D1968A3018 | 1968A3018 | 1.9 | 0.20 (0.09) |
| | | | 1/2 | 1/2 | 3/8 | D1968A4018 | 1968A4018 | 2.8 | 0.34 (0.15) |
| | | Tubo Fission | 1/8 | 1/8 | 1/4 | D1968A1118# | 1968A1118# | 0.3 | 0.08 (0.04) |
| | | | 1/4 | 1/4 | 1/4 | D1968A2118 | 1968A2118 | 0.6 | 0.14 (0.06) |
| | | Tube Fitting | 3/8 | 3/8 | 3/8 | D1968A3118 | 1968A3118 | 1.9 | 0.20 (0.09) |
| | | | 1/2 | 1/2 | 3/8 | - | _ | 2.8 | 0.34 (0.15) |
| # These models have 1/8 threaded outlet, but with 1/4 inlet tube fittings. | | | | | | | | | |

























Notes



Notes

CAUTIONS, WARNINGS And STANDARD WARRANTY



ROSS OPERATING VALVE, ROSS CONTROLS®, ROSS DECCO®, and AUTOMATIC VALVE INDUSTRIAL, collectively the "ROSS Group".

PRE-INSTALLATION or SERVICE

- 1. Before servicing a valve or other pneumatic component, be sure all sources of energy are turned off, the entire pneumatic system is shut down and exhausted, and all power sources are locked out (ref: OSHA 1910.147, EN 1037).
- 2. All ROSS Group Products, including service kits and parts, should be installed and/or serviced only by persons having training and experience with pneumatic equipment. Because any product can be tampered with and/or need servicing after installation, persons responsible for the safety of others or the care of equipment must check ROSS Group Products on a regular basis and perform all necessary maintenance to ensure safe operating conditions.
- 3. All applicable instructions should be read and complied with before using any fluid power system to prevent harm to persons or equipment. In addition, overhauled or serviced valves must be functionally tested prior to installation and use. If you have any questions, call your nearest ROSS Group location.
- 4. Each ROSS Group Product should be used within its specification limits. In addition, use only ROSS Group components to repair ROSS Group Products.

WARNINGS

Failure to follow these instructions can result in personal injury and/or property damage.

FILTRATION and LUBRICATION

- 1. Dirt, scale, moisture, etc., are present in virtually every air system. Although some valves are more tolerant of these contaminants than others, best performance will be realized if a filter is installed to clean the air supply, thus preventing contaminants from interfering with the proper performance of the equipment. The ROSS Group recommends a filter with a 5-micron rating for normal applications.
- 2. All standard ROSS Group filters and lubricators with polycarbonate plastic bowls are designed for compressed air applications only. Use the metal bowl guard, where provided, to minimize danger from high pressure fragmentation in the event of bowl failure. Do not expose these products to certain fluids, such as alcohol or liquefied petroleum gas, as they can cause bowls to rupture, creating a combustible condition and hazardous leakage. Immediately replace crazed, cracked, or deteriorated bowls.
- 3. Only use lubricants which are compatible with materials used in the valves and other components in the system. Normally, compatible lubricants are petroleum base oils with oxidation inhibitors, an aniline point between 180°F (82°C) and 220°F (104°C), and an ISO 32, or lighter, viscosity. Avoid oils with

phosphate type additives which can harm polyurethane components, potentially leading to valve failure which risks personal injury, and/or damage to property.

WARNINGS:

Failure to follow these instructions can result in personal injury and/or property damage.

AVOID INTAKE/EXHAUST RESTRICTION

- 1. Do not restrict air flow in the supply line. To do so could reduce the pressure of the supply air below minimum requirements for the valve and thereby causing erratic action.
- 2. Do not restrict a valve's exhaust port as this can adversely affect its operation. Exhaust silencers must be resistant to clogging and must have flow capacities at least as great as the exhaust capacities of the valves. Contamination of the silencer can result in reduced flow and increased back pressure.

WARNINGS: Failure to follow these instructions can result in personal injury and/or property damage.

SAFETY APPLICATIONS

- 1. Mechanical Power Presses and other potentially hazardous machinery using a pneumatically controlled clutch and brake mechanism must use a press control double valve with a monitoring device. A double valve without a self-contained monitoring device should be used only in conjunction with a control system which assures monitoring of the valve. All double valve installations involving hazardous applications should incorporate a monitoring system which inhibits further operation of the valve and machine in the event of a failure within the valve mechanism.
- 2. Safe Exhaust (dump) valves without a self-contained monitoring device should be used only in conjunction with a control system which assures monitoring of the valve. All Safe Exhaust valve installations should incorporate a monitoring system which inhibits further operation of the valve and machine in the event of a failure within the valve mechanism.
- 3. Per specifications and regulations, the ROSS L-O-X® and L-O-X® with EEZ-ON®, NO6 and N16 Series operation products are defined as energy isolation devices. NOT AS EMERGENCY STOP DEVICES.

WARNINGS:

Failure to follow these instructions can result in personal injury and/or property damage.

STANDARD WARRANTY

All products sold by the ROSS Group are warranted for a one-year period [with the exception of Filters, Regulators and Lubricators ("FRLs") which are warranted for a period of seven (7) years] from the date of purchase. All products are, during their respective warranty periods, warranted to be free of defects in material and workmanship. The ROSS Group's obligation under this warranty is limited to repair, replacement or refund of the purchase price paid for products which the ROSS Group has determined, in its sole discretion, are defective. All warranties become void if a product has been subject to misuse, misapplication, improper maintenance, modification or tampering. Products for which warranty protection is sought must be returned to the ROSS Group freight prepaid.

THE WARRANTY EXPRESSED ABOVE IS IN LIEU OF AND EXCLUSIVE OF ALL OTHER WARRANTIES AND THE ROSS GROUP EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES EITHER EXPRESSED OR IMPLIED WITH RESPECT TO MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THE ROSS GROUP MAKES NO WARRANTY WITH RESPECT TO ITS PRODUCTS MEETING THE PROVISIONS OF ANY GOVERNMENTAL OCCUPATIONAL SAFETY AND/OR HEALTH LAWS OR REGULATIONS. IN NO EVENT IS THE ROSS GROUP LIABLE TO PURCHASER, USER, THEIR EMPLOYEES OR OTHERS FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES WHICH MAY RESULT FROM A BREACH OF THE WARRANTY DESCRIBED ABOVE OR THE USE OR MISUSE OF THE PRODUCTS. NO STATEMENT OF ANY REPRESENTATIVE OR EMPLOYEE OF THE ROSS GROUP MAY EXTEND THE LIABILITY OF THE ROSS GROUP AS SET FORTH HEREIN.



| | , | | | |
|----------------|--------------------------------|----------------|---------------------------|---------------------------|
| Americas | ROSS CONTROLS | USA | Tel: +1-248-764-1800 | www.rosscontrols.com |
| | ROSS CONTROLS CANADA Ltd. | Canada | Tel: +1-416-251-7677 | www.rosscanada.com |
| | ROSS DO BRASIL EIRELI | Brazil | Tel: +55-11-4335-2200 | www.rosscontrols.com.br |
| | ROSS EUROPA GmbH | Germany | Tel: +49 (0)6103-7597-100 | www.rosseuropa.com |
| EUROPE | ROSS FRANCE SAS | France | Tel: +33-(0)1-49-45-65-65 | www.rossfrance.com |
| | ROSS PNEUMATROL Ltd. | United Kingdom | Tel: +44 (0)1254 872277 | www.rossuk.co.uk |
| | ROSS CONTROLS INDIA Pvt. Ltd. | India | Tel: +91-44-2624-9040 | www.rosscontrolsindia.com |
| ASIA & PACIFIC | ROSS CONTROLS (CHINA) Ltd. | China | Tel: +86-21-6915-7961 | www.rosscontrolschina.com |
| | ROSS ASIA K.K. | Japan | Tel: +81-42-778-7251 | www.rossasia.co.jp |
| | AUTOMATIC VALVE INDUSTRIAL LLC | USA | Tel: +1-248-474-6700 | www.automaticvalve.com |
| | ROSS DECCO COMPANY | USA | Tel: +1-248-764-1800 | www.rossdecco.com |
| | ROSS PNEUMATROL Ltd. | United Kingdom | Tel: +44 (0)1254 872277 | www.pneumatrol.com |
| | manufactIS GmbH | Germany | Tel: +49 (0)2013-16843-0 | www.manufactis.net |
| | | | | |

Full-Service Global Locations

There are ROSS Distributors Throughout the World

To meet your requirements across the globe, ROSS distributors are located throughout the world. Through ROSS or its distributors, guidance is available for the selection of ROSS products, both for those using fluid power components for the first time and those designing complex systems.

Other literature is available for engineering, maintenance, and service requirements.

If you need products or specifications not shown in this catalog, please visit ROSS' website, contact ROSS or your ROSS distributor. The ROSS Support Team will be happy to assist you in selecting the best product for your application.

For a current list of countries and local distributors, visit ROSS' at www.rosscontrols.com.