

EUROCARD HOLDER

SKP 31/II

Screw terminals 31-pole (DIN 41617)


Connection via double row terminals on one side


With the vertical snap adapter SASA 135 Art.-No. 63900 the holder can be mounted at right-angles on the rail. The D2 size is for a card without a front plate.

Link to Product

Illustration







Product may differ from Image

Technical Data	
Operating voltage	250 V AC
Operating current	max. 5 A
Material group	EN 60664-1 over voltage, category I
Material	Plastic, flame retardant
Configuration	31-pole (DIN 41617)
General data	
Mounting method	DIN-rail mountable (EN 60715) or screw fixing
Connection	4 mm² single core
Dimensions H×W×D	137×63×170 mm

The information in this brochure has been compiled with the utmost care.

Liability for the correctness completeness and topicality of the information is restricted to gross negligence. Version: 2022-11-13



Description	
Functional description	To insert the card first press down the 2 yellow buttons. Then slide the Eurocard into the guide slots pushing until fully engaged. The card is now locked into position. It can be removed by pressing down on the 2 yellow buttons.
Product article number of manufacturer	63007