


DIRECTIONAL CONTROL VALVES ISO 15407-2 W66 SERIES

PRODUCT CATALOG





ISO 15407-2 Valves W66 Series

Product Overview

The ROSS® 15407-2 valves W66 Series are base mounted spool and sleeve valves that conform to the ISO standards 15407-2 mounting interface. Manifold bases feature modular plug-together electrical connections terminating at end plates, offering a variety of terminal strip or multi-pin interfaces.

These ISO Size 0 (26mm) and 00 (18mm) valves are available as, 2- and 3-position, 5-ported 4-way valves. Solenoid pilot options include a locking or non-locking override, and either internal or external pilot supply. The spool and sleeve design means there are no seals to wear out.




Illustration examples.

15407-2: Plug-in Standards for Size 01 (26mm) & Size 02 (18mm) Wide Valves



VALVE FEATURES

Spool and Sleeve Design	Spool and Sleeve construction for high dirt tolerance; no seals to wear out	
Mounting Options	Individual sub-base or manifold base mounting	
Pilot Supply	Internal or external; suitable for vacuum service (with external pilot supply)	
Pilot Operation	Provides high shifting force with low power consumption	

	Port	Sizes	izes Functions		Actuation					
		5/2 5/3								
ISO Size	1/8	1/4	Single	Double	Closed Center	Open Center	Pressure Center	Solenoid Control	Maximum Flow C _v	Page
02 (18mm)	•		•	•	•	•	•	•	1.0	0 7
01 (26mm)		•	•	•	•	•		•	2.5	3 – 7
Sub-Bases & Manifold Bases					8 – 9					
Accessories and Options	Accessories and Options				10					

Specifications




STANDARD SPECIFICATIONS					
	Function		5/2 and 5/3 Valve		
	Construction Design		Spool and Sleeve		
GENERAL	Actuation		Electrical – Solenoid Pilot Controlled		
UENERAL	Mounting		Sub-Base or Manifold		
	Connection		Threaded; G, NPT		
	Manual Override		Flush; rubber, non-locking		
	Tananaratura	Colon aid Dilet Controlled	Ambient	F0 to 1000F / 1F0 to F000\	
	Temperature	Solenoid Pilot Controlled	Media	5° to 120°F (-15° to 50°C)	
	Flow Media		Filtered air		
OPERATING	Operating Pressure		Vacuum to 145 psig (Vacuum to	9.9 bar)	
CONDITIONS	Pilot Supply Pressure	5/2 Valves	ISO Size 02 (18mm)	30 psig (2.07 bar)	
			ISO Size 01 (26mm)	25 psig (1.73 bar)	
		5/3 Valves	35 psig (2.41 bar)		
External Pilot Supply		Must be equal to or greater than inlet pressure			
			Power Consumption	Operating Voltage (each solenoid)	
ELECTRICAL			24 volts DC	6 watts	
DATA FOR	Solenoids		120 volts AC 60 Hz	— 11 VA inrush, 8.5 VA holding	
SOLENOID PILOT			230-240 volts AC, 60 Hz	TT VA III usii, 6.5 VA iioluliig	
			Bi-polar, surge suppression (star	ndard)	
			Indicator Light – One per solenoid		
	Valve Body		Cast Aluminum		
CONSTRUCTION	End Caps		Polybutylene Terephthalate (PBT)		
MATERIAL	Fasteners		Zinc Plated Steel		
Coils		Thermoset Plastic			

	PROD	OUCT CREDENTIALS	
CSA Certificate of Compliance	Declaration of Conformity CE EAC		CRN Certification
C ⊕® US	C€	EAC	Available for appropriately tested valves

Ordering Information

5/2 Solenoid Pilot Controlled Valves




ISO Size	Valve Actuation	Flow C _V	Weight Ib (kg)
02 (18 mm)	Single Solenoid Pilot	0.55	0.3 (0.15)
	Double Solenoid Pilot	0.55	0.4 (0.16)
01 (26mm)	Single Solenoid Pilot	1.10	0.6 (0.25)
	Double Solenoid Pilot	1.10	

Valve Schematic				
Single Solenoid Pilot Controlled	Double Solenoid Pilot Controlled			
Sol. 14 D T V V T V V T V V T V V T V V V T V V V T V	Sol. 14 Sol. 12			

Valve Technical Data



5/2 Solenoid Pilot Controlled Valves




For additional information, and to assist you with piping and connectivity designs, our products are available in downloadable 2D drawings and 3D CAD models in a wide range of options including native formats. Please visit www.rosscontrols.com.

Ordering Information

01 (26mm)

5/3 Double Solenoid Pilot Controlled Valves



ISO Size	Valve Actuation	Flow C _V	Weight Ib (kg)
02 (18 mm)	Double Solenoid Pilot	0.55	0.4 (0.16)

1.10

Double Solenoid Pilot


Valve Schematic					
Closed Center	Power Center	Open Center			
#14	#14	#14 D 4 2 #12 #12 5 A 3			

0.6 (0.25)


Valve Technical Data




5/3 Double Solenoid Pilot Controlled Valves



MANIFOLD BASES WITH END PORTS



END STATIONS



BLANK STATIONS

	ISO Size	Model Number*		
Blank Stations	02 (18mm)	RPS5634P		
	01 (26mm)	RPS5534P		
	* Includes: Blank Station Plate, Gasket, and Mounti	ng Bolts.	0	





GASKET KITS

	Pilots Status	Kit Diagram Reference	Description	Kit Number
		1	Supply & Exhaust & Pilots Open	RPSHU11P
	Pilots Opened	2	Supply Closed, Exhaust & Pilots Open	RPSHU12P
Gasket Kits Manifold to Manifold		3	Supply & Exhaust Closed, Pilots Open	RPSHU13P
		4	Supply & Pilots Open, Exhaust Closed	RPSHU14P
	Pilots Blocked 7 8	5	Supply & Exhaust Open, Pilots Closed	RPSHU15P
		6	Supply & Pilots Closed, Exhaust Open	RPSHU16P
		Supply & Exhaust & Pilots Closed	RPSHU17P	
		8	Supply Open, Exhaust & Pilots Closed	RPSHU18P



1 – Supply & Exhaust & Pilots Open





3 - Supply & Exhaust Closed, Pilots Open



2 – Supply Closed, Exhaust & Pilots Open 4 – Supply & Pilots Open, Exhaust Closed



5 - Supply & Exhaust Open, Pilots Closed



6 - Supply & Pilots Closed, Exhaust Open





8 - Supply Open, Exhaust & Pilots Closed

INTERPOSED SUPPLY & EXHAUST MODULES

Interposed Supply & Exhaust **Modules**

ISO Size	Outlet Port	Model Number*		
100 0120		G Thread	NPT Thread	
02 (18mm)	Supply	RPS561600P	RPS561601P	
	Exhaust	RPS561700P	RPS561701P	
01 (06mm)	Supply	RPS551600P	RPS551601P	
01 (26mm) Exhaust		RPS551700P	RPS551701P	

^{*} Used on Size 00 & Size 0 valves to provide a pressure or exhaust path to individual valves.



INTERPOSED FLOW CONTROL


Interposed Flow Controls

ISO Size	Model Number*
02 (18mm)	RPS5635P
01 (26mm)	RPS5535P

^{*} Both adjustment screws are located on the 12 end of the unit. Interposed Flow Control mounts with its own studs, which means the valve uses standard bolts for mounting. Interposed Flow Control is not to be used as a shut off device and is not bubble tight when needles are fully turned down.



INTERPOSED PRESSURE REGULATORS



Pressure Regulators

* For Common Pressure Regulator Option, Regulator Gauge callout must be the same number for both Port #4 and Port #2. (Example: 166)

Remote Air Pilot Operated for hard-to-reach pressure control Unregulated Pilot Pressure to valve for consistent valve shifting regardless of pressure adjustment.



GAUGE ADAPTER KITS

Gauge Adapter

Description	Model Number
Gauge Adapter Kit	RPS5651160P
1/8" Female to 1/8" Female Coupling	R207P-2*
1/8" Male to 1/8" Male Long Nipple	RVS215PNL-2-15*
* Included in Gauge Adapter RPS5651160P.	
Included with all Size 02 Regulators. Both kits are required of	on all Size 01 & 02 Regulators when the Regulator is on



EXHAUST SILENCERS

the last Station on the Right (14) End.

Silencers	Port Size	Thread Type	Model Number		Flow	Pressure Range
			R/Rp Thread	NPT Thread	Avg. C _v	psig (bar)
	1/4	Male	D5500A2003	5500A2003	2.1	0-290 (0-20) maximum

CAUTIONS, WARNINGS And STANDARD WARRANTY



ROSS OPERATING VALVE, ROSS CONTROLS®, ROSS DECCO®, and AUTOMATIC VALVE INDUSTRIAL, collectively the "ROSS Group".

PRE-INSTALLATION or SERVICE

- 1. Before servicing a valve or other pneumatic component, be sure all sources of energy are turned off, the entire pneumatic system is shut down and exhausted, and all power sources are locked out (ref: OSHA 1910.147, EN 1037).
- 2. All ROSS Group Products, including service kits and parts, should be installed and/or serviced only by persons having training and experience with pneumatic equipment. Because any product can be tampered with and/or need servicing after installation, persons responsible for the safety of others or the care of equipment must check ROSS Group Products on a regular basis and perform all necessary maintenance to ensure safe operating conditions.
- 3. All applicable instructions should be read and complied with before using any fluid power system to prevent harm to persons or equipment. In addition, overhauled or serviced valves must be functionally tested prior to installation and use. If you have any questions, call your nearest ROSS Group location.
- 4. Each ROSS Group Product should be used within its specification limits. In addition, use only ROSS Group components to repair ROSS Group Products.

WARNINGS:

Failure to follow these instructions can result in personal injury and/or property damage.

FILTRATION and LUBRICATION

- 1. Dirt, scale, moisture, etc., are present in virtually every air system. Although some valves are more tolerant of these contaminants than others, best performance will be realized if a filter is installed to clean the air supply, thus preventing contaminants from interfering with the proper performance of the equipment. The ROSS Group recommends a filter with a 5-micron rating for normal applications.
- 2. All standard ROSS Group filters and lubricators with polycarbonate plastic bowls are designed for compressed air applications only. Use the metal bowl guard, where provided, to minimize danger from high pressure fragmentation in the event of bowl failure. Do not expose these products to certain fluids, such as alcohol or liquefied petroleum gas, as they can cause bowls to rupture, creating a combustible condition and hazardous leakage. Immediately replace crazed, cracked, or deteriorated bowls.
- 3. Only use lubricants which are compatible with materials used in the valves and other components in the system. Normally, compatible lubricants are petroleum base oils with oxidation inhibitors, an aniline point between 180°F (82°C) and 220°F (104°C), and an ISO 32, or lighter, viscosity. Avoid oils with

phosphate type additives which can harm polyurethane components, potentially leading to valve failure which risks personal injury, and/or damage to property.

WARNINGS:

Failure to follow these instructions can result in personal injury and/or property damage.

AVOID INTAKE/EXHAUST RESTRICTION

- 1. Do not restrict air flow in the supply line. To do so could reduce the pressure of the supply air below minimum requirements for the valve and thereby causing erratic action.
- 2. Do not restrict a valve's exhaust port as this can adversely affect its operation. Exhaust silencers must be resistant to clogging and must have flow capacities at least as great as the exhaust capacities of the valves. Contamination of the silencer can result in reduced flow and increased back pressure.

WARNINGS: Failure to follow these instructions can result in personal injury and/or property damage.

SAFETY APPLICATIONS

- 1. Mechanical Power Presses and other potentially hazardous machinery using a pneumatically controlled clutch and brake mechanism must use a press control double valve with a monitoring device. A double valve without a self-contained monitoring device should be used only in conjunction with a control system which assures monitoring of the valve. All double valve installations involving hazardous applications should incorporate a monitoring system which inhibits further operation of the valve and machine in the event of a failure within the valve mechanism.
- 2. Safe Exhaust (dump) valves without a self-contained monitoring device should be used only in conjunction with a control system which assures monitoring of the valve. All Safe Exhaust valve installations should incorporate a monitoring system which inhibits further operation of the valve and machine in the event of a failure within the valve mechanism.
- 3. Per specifications and regulations, the ROSS L-O-X® and L-O-X® with EEZ-ON®, NO6 and N16 Series operation products are defined as energy isolation devices. NOT AS EMERGENCY STOP DEVICES.

WARNINGS:

Failure to follow these instructions can result in personal injury and/or property damage.

STANDARD WARRANTY

All products sold by the ROSS Group are warranted for a one-year period [with the exception of Filters, Regulators and Lubricators ("FRLs") which are warranted for a period of seven (7) years] from the date of purchase. All products are, during their respective warranty periods, warranted to be free of defects in material and workmanship. The ROSS Group's obligation under this warranty is limited to repair, replacement or refund of the purchase price paid for products which the ROSS Group has determined, in its sole discretion, are defective. All warranties become void if a product has been subject to misuse, misapplication, improper maintenance, modification or tampering. Products for which warranty protection is sought must be returned to the ROSS Group freight prepaid.

THE WARRANTY EXPRESSED ABOVE IS IN LIEU OF AND EXCLUSIVE OF ALL OTHER WARRANTIES AND THE ROSS GROUP EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES EITHER EXPRESSED OR IMPLIED WITH RESPECT TO MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THE ROSS GROUP MAKES NO WARRANTY WITH RESPECT TO ITS PRODUCTS MEETING THE PROVISIONS OF ANY GOVERNMENTAL OCCUPATIONAL SAFETY AND/OR HEALTH LAWS OR REGULATIONS. IN NO EVENT IS THE ROSS GROUP LIABLE TO PURCHASER, USER, THEIR EMPLOYEES OR OTHERS FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES WHICH MAY RESULT FROM A BREACH OF THE WARRANTY DESCRIBED ABOVE OR THE USE OR MISUSE OF THE PRODUCTS. NO STATEMENT OF ANY REPRESENTATIVE OR EMPLOYEE OF THE ROSS GROUP MAY EXTEND THE LIABILITY OF THE ROSS GROUP AS SET FORTH HEREIN.



	,			
AMERICAS	ROSS CONTROLS	USA	Tel: +1-248-764-1800	www.rosscontrols.com
	ROSS CONTROLS CANADA Ltd.	Canada	Tel: +1-416-251-7677	www.rosscanada.com
	ROSS DO BRASIL EIRELI	Brazil	Tel: +55-11-4335-2200	www.rosscontrols.com.br
EUROPE ASIA & PACIFIC	ROSS EUROPA GmbH	Germany	Tel: +49 (0)6103-7597-100	www.rosseuropa.com
	ROSS FRANCE SAS	France	Tel: +33-(0)1-49-45-65-65	www.rossfrance.com
	ROSS PNEUMATROL Ltd.	United Kingdom	Tel: +44 (0)1254 872277	www.rossuk.co.uk
	ROSS CONTROLS INDIA Pvt. Ltd.	India	Tel: +91-44-2624-9040	www.rosscontrolsindia.com
	ROSS CONTROLS (CHINA) Ltd.	China	Tel: +86-21-6915-7961	www.rosscontrolschina.com
	ROSS ASIA K.K.	Japan	Tel: +81-42-778-7251	www.rossasia.co.jp
	AUTOMATIC VALVE INDUSTRIAL LLC	USA	Tel: +1-248-474-6700	www.automaticvalve.com
	ROSS DECCO COMPANY	USA	Tel: +1-248-764-1800	www.rossdecco.com
	ROSS PNEUMATROL Ltd.	United Kingdom	Tel: +44 (0)1254 872277	www.pneumatrol.com
	manufactIS GmbH	Germany	Tel: +49 (0)2013-16843-0	www.manufactis.net

Full-Service Global Locations

There are ROSS Distributors Throughout the World

To meet your requirements across the globe, ROSS distributors are located throughout the world. Through ROSS or its distributors, guidance is available for the selection of ROSS products, both for those using fluid power components for the first time and those designing complex systems.

Other literature is available for engineering, maintenance, and service requirements.

If you need products or specifications not shown in this catalog, please visit ROSS' website, contact ROSS or your ROSS distributor. The ROSS Support Team will be happy to assist you in selecting the best product for your application.

For a current list of countries and local distributors, visit ROSS' at www.rosscontrols.com.