

SAFE LOAD HOLDING PO CHECK VALVES 19 & 27 SERIES

PRODUCT CATALOG






Right Angle Pilot Operated Check Valves 19 Series Product Overview

Pilot Operated Check Function

Pilot Operated Check valves are designed to trap pressure in order to hold a cylinder in place when a safety event occurs.





Pilot Operated Check Valves are used to block the return of air from cylinders or other devices.

Air flows freely from port 1 to port 2, but a signal at port 12 is required to allow flow in the reverse direction from port 2 to port 1.


Right-angle models with threaded Banjo are designed for easy positioning of pipe or tubing.

VALVE FEATURES					
Design	Right-angle design for easy positioning of pipe or tubing				
Mounting					
Connectivity	Right Angle Valves with Threaded Banjo or Push-to-Connect Fitting				
Ease of Maintenance	Ce Lube or non-lube operation				
	PRODUCT CREDENTIALS				
Safety Ca	Safety Category EAC Conformity Declaration				
Cat. 1 PL c	SIL 2 Functional Safety				

Specifications



		STANDARI) SPECIFICATIONS			
	Function		Safe Load Holding			
	Construction Design		Poppet			
	Actuation		Pneumatic			
GENERAL	Mounting		Directly in cylinder ports			
GENERAL		Tuno	Threaded; G, NPT			
	Connection	Type	Push-in-tubing ports			
		Orientation	Any			
	Minimum Operation Frequency		Once per month, to ensure proper function			
	Temperature	Ambient	450.4.4005.4400.4.7000			
OPERATING		Media	15° to 160°F (-10° to 70°C)			
CONDITIONS	Flow Media		Filtered air			
	Operating Pressure		5 to 150 psig (0.3 to 10 bar)			
	Valve Body		Nickel Plated Brass and Anodized Aluminum			
CONSTRUCTION	Poppet		Acetal and Stainless Steel			
MATERIAL	Seals		Buna-N; Fluorocarbon			
	Manual Override		Valve equipped with port, manual override adapter available			
	IMPORTANT NOTE: Please read carefully and thoroughly all of the CAUTIONS, WARNINGS on the inside back cover.					



Ordering Information

1/8

1/4

3/8

1/2

1/8

1/4

3/8

1/2

Filot Operated Glieck Hight Angle Valves with Hilleaded Danjo								
Port Size								
Port 1 (female thread)	Port 2 (male thread)	Port Thread	Valve Model Number	Port 12				
1/8	1/8	G	D1958A1010					
1/4	1/4	G	D1958A2010	ME				
3/8	3/8	G	D1958A3010	M5				
1/2	1/2	G	D1958A4010					

NPT

NPT

NPT

NPT

Port Size	Port Thread		Tightening Torque Max.	
1 011 0120		1-2	2-1	Ft-Ib (Nm)
1/8	G	0.4	0.4	7.38 (10)
1/4	G	0.8	0.7	8.85 (12)
3/8	G	1.2	1.3	14.75 (20)
1/2	G	2.3	2.2	22.13 (30)
1/8	NPT	0.4	0.4	22.13 (30)
1/4	NPT	0.8	0.7	14.75 (20)
3/8	NPT	1.2	1.3	22.13 (30)
1/2	NPT	2.3	2.2	29.50 (40)

Manual
Override

Manual Trapped Pressure Relief Adapter							
Port 1 Port 2 Port Thread Model Number*							
M5	M5 M5 Manual Operated Check		D1998A1010				
10/32 tubing 5/32 Manual Operated Check NPT 1998A1015							
* Adapter threads into the s	ignal port.						

1958A1010

1958A2010

1958A3010

1958A4010

Valve Schematic



10-32 UNF

Ordering Information

Port 1 tubing size in inches (") or millimeters (mm).



Pilot Operated Check Right Angle Valves with Push-to-Connect Fitting Port Size Port 2 Valve Model Number Port 12 Port 2 **Thread Type** Port 1# (male thread) (tube fittings) 4 mm 1/8 G D1958A1140 6 mm 1/8 G D1958A1160 8 mm 1/8 G D1958A1180 M5 6 mm 1/4 G D1958A2160 1/4 G D1958A2180 8 mm 10 mm 3/8 G D1958A3110 5/32" 1/8 NPT 1958A1115 1/8 NPT 1958A1120 1/4" 1/4 NPT 1958A2120 10-32 UNF 1/4 NPT 1958A2130 3/8" 3/8 NPT 1958A3130


Port Size		Port 2	Port 2 C _v		Tightening Torque Max.	
Port 1# (tube fittings)	Port 2 (male thread)	Thread Type	1-2	2-1	Ft-lb (Nm)	
4 mm	1/8	G	0.4	0.4		
6 mm	1/8	G	0.4	0.4	7.38 (10)	
8 mm	1/8	G	0.4	0.4		
6 mm	1/4	G	0.8	0.7	0.05 (40	
8 mm	1/4	G	0.8	0.7	8.85 (12	
10 mm	3/8	G	1.2	1.3	14.75 (20	
5/32"	1/8	NPT	0.4	0.4	11.00 (15)	
4 /42	1/8	NPT	0.4	0.4	11.06 (15)	
1/4"	1/4	NPT	0.8	0.7	14.75 (00)	
0./02	1/4	NPT	0.8	0.7	14.75 (20)	
3/8"	3/8	NPT	1.2	1.3	22.13 (30)	
Port 1 tubing size in inc	ches (") or millimeters (n	ım).			·	


	Manual Trapped Pressure Relief Adapter					
Manual	Port 1 (male thread)	Port 2	Port Thread	Model Number*		
Override	M5	M5 Manual Operated Check	G	D1998A1010		
	10/32 tubing	5/32 – Manual Operated Check	NPT	1998A1015		
	* Adapter threads into the s	ignal port.				

Valve Schematic

- D


Right Angle Pilot Operated Check Valves with Threaded Banjo








Right Angle Pilot Operated Check Valves with Push-to-Connect Fitting





Pilot Operated Check Valves 27 Series Product Overview

Pilot Operated Check Function

Pilot Operated Check valves are used for load holding or cylinder position holding applications, designed to trap pressure in order to hold a cylinder in place when a safety event occurs.




Illustration examples.

Pilot Operated Check valves can be used wherever a high-flow or remotely-controlled checking function is needed. Can be used in a circuit to provide automatic stopping of a cylinder in the event of the loss of electrical or pneumatic power.

VALVE FEATURES						
Poppet Design	Poppet construction for near zero leakage					
Trapped Pressure Release Options	Manual or remote trapped pressure release when pressure is removed from the Blowdown Signal Port (BP)					
Mounting	Inline					

PRODUCT CREDENTIALS								
Safety Category	EAC Declaration of Conformity	ISO Standard	CSA Certificate of Compliance	CRN Certification				
Cat. 1 SIL 2 Functional Safety	ERC	ISO 13849-1:2015	Solenid Pilot Valves	Available for appropriately tested valves				

Specifications



STANDARD SPECIFICATIONS						
	Function		2/2 Valves			
	Construction Design		Poppet			
	Actuation		Electrical - Solenoid Pilot Controlled			
GENERAL			Pneumatic - Pressure Controlled Valves			
GENERAL	Mounting	Туре	Inline			
	Widunting	Orientation	Any, preferably vertical			
	Connection		Threaded; G, NPT			
	Minimum Operation Fre	quency	Once per month, to ensure proper ful	nction		
		Ambient				
	Temperature	Media	- 40° to 175°F (4° to 80°C)			
OPERATING	Flow Media		Filtered air			
CONDITIONS	0 11 0	Solenoid Pilot Controlled	15 to 150 psig (1 to 10.3 bar)			
	Operating Pressure	Pressure Controlled	30 to 150 psig (2 to 10.3 bar)			
	Pilot Pressure		Must be equal to or greater than inlet pressure			
			Operating Voltage	Power Consumption (each solenoid)		
			24 valta DC	4-pin Micro connector – 4.5 watts		
ELECTRICAL	Solenoid		24 volts DC	3-pin Mini connector – 60 watts		
DATA FOR SOLENOID PILOT			110-120 volts AC, 50/60 Hz	8 VA inrush, 6 VA holding		
CONTROLLED VALVES			230-240 volts AC, 50/60 Hz	o va ilitusii, o va iloiuilig		
			Rated for continuous duty			
	Enclosure Rating		IP65, IEC 60529			
	Electrical Connection		EN DIN 175301-803 Form A, 3-Pin Mini or 4-Pin Micro.			
	Valve Body		Cast Aluminum			
CONSTRUCTION MATERIAL	Poppet		Acetal and Stainless Steel			
	Seals		Buna-N			
	IMPORTANT NOTE: Please read carefully and thoroughly all of the CAUTIONS, WARNINGS on the inside back cover.					


Applications

Solenoid Pilot Controlled Valve Application

Dual Pilot Operated Check Valve

CIRCUIT FEATURES

- To operate cylinder, simultaneously energize solenoids A and C or B and C.
- · Pilot supply and exhaust are independent of control valve.
- · Response time is not affected by exhaust restrictions of the control valve.
- Cylinder remains stationary if neither control valve solenoid is energized, or if electrical signal is lost.
- · Pressure in cylinder is exhausted when the air supply at "P" port is lost or locked-out.
- L-O-X® valve provides lockable shut-off of air supply, and exhausting of trapped downstream air.




Pressure Controlled Valve Application

Single Pilot Operated Check Valve

CIRCUIT FEATURES


- · Cylinder moves as long as the control valve solenoid is energized. Use for continuous motion or jogging.
- · Cylinder remains stationary if neither control valve solenoid is energized, or if electrical signal is lost.



Single Pilot Operated Check Valve

CIRCUIT FEATURES


- Cylinder moves as long as the control valve solenoid is energized. Use for continuous motion or jogging.
- · Cylinder remains stationary if neither control valve solenoid is energized, or if electrical signal is lost.



Single Pilot Operated Check Valve with Trapped Pressure Relief Application

CIRCUIT FEATURES

- Trapped pressure between check valve and cylinder is exhausted when the air supply at the
- · Blowdown Signal Port (BP) is lost or locked-out.
- Cylinder moves as long as the control valve solenoid is energized. Use for continuous motion or jogging.
- Cylinder remains stationary if neither control valve solenoid is energized, or if electrical signal is lost.



Applications




Pressure Controlled Valve Application

Single Pilot Operated Check Valve with Manual Trapped Pressure Relief

CIRCUIT FEATURES


- To operate cylinder, simultaneously energize solenoids A and C or B and C.
- Pilot supply and exhaust are independent of control valve.
- Response time is not affected by exhaust restrictions of the control valve.
- · Cylinder remains stationary if neither control valve solenoid is energized, or if electrical signal is lost.
- Pressure in cylinder is exhausted when the air supply at "P" port is lost or locked-out.
- L-O-X® valve provides lockable shut-off of air supply, and exhausting of trapped downstream air.



Single Pilot Operated Check Valve

CIRCUIT FEATURES


- Cylinder moves as long as the control valve solenoid is energized. Use for continuous motion or jogging.
- · Cylinder remains stationary if neither control valve solenoid is energized, or if electrical signal is lost.



Single Pilot Operated Check Valve

CIRCUIT FEATURES


- Cylinder moves as long as the control valve solenoid is energized. Use for continuous motion or jogging.
- Cylinder remains stationary if neither control valve solenoid is energized, or if electrical signal is lost.



Dual Pilot Operated Check Valve Manual Trapped Pressure Relief

CIRCUIT FEATURES

- Trapped pressure between check valve and cylinder is exhausted when the air supply at the
- · Blowdown Signal Port (BP) is lost or locked-out.
- · Cylinder moves as long as the control valve solenoid is energized. Use for continuous motion or jogging.
- · Cylinder remains stationary if neither control valve solenoid is energized, or if electrical signal is lost.



Ordering Information – Solenoid Pilot Controlled Valves

Dual Pilot Operated Check – Valves with Remote Trapped Pressure Relief

Valves with DIN EN Connector 2-Way 2-Position Valves							
		Valve Model Number					
Port Size		G Thread		NPT Thread			
	24 V DC	110-120 V AC	230 V AC	24 V DC	110-120 V AC	230 V AC	
3/8	D2778D3900W	D2778D3900Z	D2778D3900Y	2778D3900W	2778D3900Z	2778D3900Y	
1/2	D2778D4900W	D2778D4900Z	D2778D4900Y	2778D4900W	2778D4900Z	2778D4900Y	
3/4	D2778D5900W	D2778D5900Z	D2778D5900Y	2778D5900W	2778D5900Z	2778D5900Y	
1	D2778D6900W	D2778D6900Z	D2778D6900Y	2778D6900W	2778D6900Z	2778D6900Y	

Valves with 3-Pin Mini Connector 2-Way 2-Position Valve										
		Valve Model Number								
Port Size		G Thread		NPT Thread						
	24 V DC	110-120 V AC	230 V AC	24 V DC	110-120 V AC	230 V AC				
3/8	D2778D3901W	D2778D3901Z	D2778D3901Y	2778D3901W	2778D3901Z	2778D3901Y				
1/2	D2778D4901W	D2778D4901Z	D2778D4901Y	2778D4901W	2778D4901Z	2778D4901Y				
3/4	D2778D5901W	D2778D5901Z	D2778D5901Y	2778D5901W	2778D5901Z	2778D5901Y				
1	D2778D6901W	D2778D6901Z	D2778D6901Y	2778D6901W	2778D6901Z	2778D6901Y				

Valves with 4-Pin Micr	o Connector	2-Way 2-Position Valves
	Valve Mod	lel Number
Port Size	24 \	V DC
G Thread	G Thread	NPT Thread
3/8	D2778D3904	2778D3904
1/2	D2778D4904	2778D4904
3/4	D2778D5904	2778D5904
1	D2778D6904	2778D6904

Port Size	Signal Port	Flow C _v	Weight lb (kg)
3/8	1/8	2.9	4.0 (1.8)
1/2	1/8	3.2	4.2 (1.9)
3/4	1/8	8.5 #	4.2 (1.9)
1	1/8	8.5 #	6.1 (2.8)



Effective C_v varies with load and pressure drop. Consult ROSS for specifics on your system.

	Solenoid Pinout	Connector Wiring					
Valve Schematic	DIN EN 175301-803 Form A	DIN EN AC Mini DC Mini SCIENCIP 30 Common		DC Mini	DC Micro		
Sol C	$ \begin{array}{c c} 1 & 3 \\ & 4 \\ 1 & 2 \\ \hline & G \stackrel{?}{=} \end{array} $ 1 - Positive 2 - Negative 4 - Ground		· / · · · · · · · · · · · · · · · · · ·	30 Common SOLENOID + 24VDC	10 0 + 24 VDC SOLENOID 20 0 3 Common		

Ordering Information – Pressure Controlled Valves



Single Pilot Operated Check - Valves without Trapped Pressure Relief

Valves without Trapped Pressure Relief - GEN I 2-Way 2-Position Valves **Valve Model Number** Weight **Port Size Body Size** Signal Port Flow C_{ν} lb (kg) **G** Thread **NPT Thread** 2751A2903 1/4 3/8 D2751A2903 1/4 2.3 3/8 3/8 D2751A3901 2751A3901 1/4 3.8 1.3 (0.6) 3/8 D2751A4902 2751A4902 1/4 4 1/2 3/4 2751A4905 1/4 7.7 D2751A4905 3/4 3/4 D2751A5903 2751A5903 1/4 9 2.3 (1.0) 9 3/4 D2751A6901 2751A6901 1/4 1 1-1/4 D2751B6904 2751B6904 1/4 24 1-1/4 1-1/4 D2751B7901 2751B7901 1/4 29 6.0 (2.7) 1-1/2 1-1/4 D2751B8902 2751B8902 1/4 29

Valves without Trapped Pressure Relief - GEN II

2-Way 2-Position Valves

Port Size	Valve Mod	el Number	Signal Port	Flow C _v	Weight
1 011 0120	G Thread	NPT Thread	Orginal Fort	11010 00	lb (kg)
1/4	D2751A2908	2751A2908	1/8	2.2	
3/8	D2751A3908	2751A3908	1/8	2.9	2.3 (1.0)
1/2	D2751A4915	2751A4915	1/8	3.2	



Valves with Remote Trapped Pressure Relief

2-Way 2-Position Valves

Port Size	Valve Mod	el Number	Signal Port	Flow C _v	Weight
1 011 0120	G Thread	NPT Thread	Orginal 1 ort	11000 00	lb (kg)
3/8	D2751A3922	2751A3922	1/8	2.6	1.8 (0.8)
1/2	D2751A4922	2751A4922	1/8	2.8	1.0 (0.0)
3/4	D2751A5917	2751A5917	1/8	9.2	2.9 (3.1)



Valves with Manual Trapped Pressure Relief

2-Way 2-Position Valves

Port Size	Valve Mod	el Number	. Flow C _v	Weight	
1 011 0120	G Thread	NPT Thread	TIOW OV	lb (kg)	
3/8	D2751A3920	2751A3920	2.6	1 0 (0 0)	
1/2	D2751A4920	2751A4920	2.8	1.8 (0.8)	
3/4	D2751A5919	2751A5919	9.2	2.9 (3.1)	



None Remote Manual VP VLV CYL

BP-

Valve Schematic

www.rosscontrols.com

Ordering Information – Pressure Controlled Valves

Dual Pilot Operated Check - Pressure Controlled Valves

2-Way 2-Position Valves Valves without Trapped Pressure Relief Valve Model Number Weight **Port Size** Signal Port Flow C_v lb (kg) G Thread 3/8 2768C3900 1/8 2.9 2.0 (0.9) D2768C3900 1/2 D2768C4900 2768C4900 1/8 3.2 2.4 (1.1) 3/4 D2768C5900 2768C5900 1/8 8.5 # 3.8 (1.7) D2768A6900 2768A6900 8.5 # 6.8 (3.1)



Valves with Remote Trapped Pressure Relief

2-Way 2-Position Valves

Port Size	Valve Mod	lel Number	Signal Port	Flow C _v	Weight
Full Size	G Thread	NPT Thread	Signal Pull	FIUW C _V	lb (kg)
3/8	D2768D3901	2768D3901	1/8	2.9	2.3 (1.1)
1/2	D2768D4901	2768D4901	1/8	3.2	2.3 (1.1)
3/4	D2768D5901	2768D5901	1/8	8.5 #	3.8 (1.7)
1	D2768D6901	2768D6901	1/8	8.5 #	7.4 (3.4)



Valves with Manual Trapped Pressure Relief

2-Way 2-Position Valves

Port Size	Valve Mod	el Number	Flow C	Weight
PUIT SIZE	G Thread	NPT Thread	Flow C _v	lb (kg)
3/8	D2768D3904	2768D3904	2.9	2.3 (1.1)
1/2	D2768D4904	2768D4904	3.2	2.3 (1.1)
3/4	D2768D5904	2768D5904	8.5 #	3.8 (1.7)
1	D2768D6904	2768D6904	8.5 #	6.58 (3.0)





Valve Schematic

Trapped Pressure Relief Options

C1

None






[#] Effective C_v varies with load and pressure drop. Consult ROSS for specifics on your system.

[#] Effective C_v varies with load and pressure drop. Consult ROSS for specifics on your system.


[#] Effective C_v varies with load and pressure drop. Consult ROSS for specifics on your system.




Solenoid Pilot Controlled Valves - Dual PO Check with Remote Trapped Pressure Relief




range of options including native formats, visit www.rosscontrols.com.



Pressure Controlled Valves - Single PO Check Valves without Trapped Pressure Relief





range of options including native formats, visit www.rosscontrols.com.







Pressure Controlled Valves - Single PO Check Headline Valves without Trapped Pressure Relief






Pressure Controlled Valves - Single PO Check Valves with Remote Trapped Pressure Relief










Pressure Controlled Valves - Single PO Check Valves with Manual Trapped Pressure Relief






Pressure Controlled Valves - Dual PO Check without Trapped Pressure Relief










Pressure Controlled Valves -Dual PO Check with Remote Trapped Pressure Relief





Pressure Controlled Valves - Dual PO Check with Manual Trapped Pressure Relief







PREWIRED ELECTRICAL CONNECTORS

	Cable						Model Number			
Prewired	End 1	End 2	Connection	Quantity	Length meters	Cord Diameter	Without	Lighted Connector		or
Connectors	Connector	Cord	Odinicotion	Included	(feet)	mm	Light	24 V DC	120 V AC	230 V AC
DIN EN 1753	DIN EN 175301-803	Flying leads	Solenoid	1	2 (6.5)	6	721K77	720K77-W	720K77-Z	720K77-Y
	Form A	A Figure leads	Solellolu	1	2 (6.5)	10	371K77	383K77-W	383K77-Z	383K77-Y

ELECTRICAL CONNECTORS

	Connector					Model Number			
	Туре	Connection	Fitting Connection	Quantity	Quantity Cord Diameter With		Lighted Connector		r
Connectors	Турс	Commedium	Titting Connection	Included	mm	Without Light	24 V DC	120 V AC	230 V AC
	DIN EN 175301-803	Solenoid	Cable grip	1	8 to 10	937K87	936K87-W	936K87-Z	936K87-Y
	Form A		1/2" NPT conduit	1	_	723K77	724K77-W	724K77-Z	724K77-Y

Connectors Pinout

DIN EN 175301-803 Form A



- 1 Black
- 2 Black 4 Green/Yellow (Ground)

Notes

Notes



Notes

CAUTIONS, WARNINGS And STANDARD WARRANTY



ROSS OPERATING VALVE, ROSS CONTROLS®, ROSS DECCO®, and AUTOMATIC VALVE INDUSTRIAL, collectively the "ROSS Group".

PRE-INSTALLATION or SERVICE

- 1. Before servicing a valve or other pneumatic component, be sure all sources of energy are turned off, the entire pneumatic system is shut down and exhausted, and all power sources are locked out (ref: OSHA 1910.147, EN 1037).
- 2. All ROSS Group Products, including service kits and parts, should be installed and/or serviced only by persons having training and experience with pneumatic equipment. Because any product can be tampered with and/or need servicing after installation, persons responsible for the safety of others or the care of equipment must check ROSS Group Products on a regular basis and perform all necessary maintenance to ensure safe operating conditions.
- 3. All applicable instructions should be read and complied with before using any fluid power system to prevent harm to persons or equipment. In addition, overhauled or serviced valves must be functionally tested prior to installation and use. If you have any questions, call your nearest ROSS Group location.
- 4. Each ROSS Group Product should be used within its specification limits. In addition, use only ROSS Group components to repair ROSS Group Products.

WARNINGS:

Failure to follow these instructions can result in personal injury and/or property damage.

FILTRATION and LUBRICATION

- 1. Dirt, scale, moisture, etc., are present in virtually every air system. Although some valves are more tolerant of these contaminants than others, best performance will be realized if a filter is installed to clean the air supply, thus preventing contaminants from interfering with the proper performance of the equipment. The ROSS Group recommends a filter with a 5-micron rating for normal applications.
- 2. All standard ROSS Group filters and lubricators with polycarbonate plastic bowls are designed for compressed air applications only. Use the metal bowl guard, where provided, to minimize danger from high pressure fragmentation in the event of bowl failure. Do not expose these products to certain fluids, such as alcohol or liquefied petroleum gas, as they can cause bowls to rupture, creating a combustible condition and hazardous leakage. Immediately replace crazed, cracked, or deteriorated bowls.
- 3. Only use lubricants which are compatible with materials used in the valves and other components in the system. Normally, compatible lubricants are petroleum base oils with oxidation inhibitors, an aniline point between 180°F (82°C) and 220°F (104°C), and an ISO 32, or lighter, viscosity. Avoid oils with

phosphate type additives which can harm polyurethane components, potentially leading to valve failure which risks personal injury, and/or damage to property.

WARNINGS:

Failure to follow these instructions can result in personal injury and/or property damage.

AVOID INTAKE/EXHAUST RESTRICTION

- 1. Do not restrict air flow in the supply line. To do so could reduce the pressure of the supply air below minimum requirements for the valve and thereby causing erratic action.
- 2. Do not restrict a valve's exhaust port as this can adversely affect its operation. Exhaust silencers must be resistant to clogging and must have flow capacities at least as great as the exhaust capacities of the valves. Contamination of the silencer can result in reduced flow and increased back pressure.

WARNINGS: Failure to follow these instructions can result in personal injury and/or property damage.

SAFETY APPLICATIONS

- 1. Mechanical Power Presses and other potentially hazardous machinery using a pneumatically controlled clutch and brake mechanism must use a press control double valve with a monitoring device. A double valve without a self-contained monitoring device should be used only in conjunction with a control system which assures monitoring of the valve. All double valve installations involving hazardous applications should incorporate a monitoring system which inhibits further operation of the valve and machine in the event of a failure within the valve mechanism.
- 2. Safe Exhaust (dump) valves without a self-contained monitoring device should be used only in conjunction with a control system which assures monitoring of the valve. All Safe Exhaust valve installations should incorporate a monitoring system which inhibits further operation of the valve and machine in the event of a failure within the valve mechanism.
- 3. Per specifications and regulations, the ROSS L-O-X® and L-O-X® with EEZ-ON®, NO6 and N16 Series operation products are defined as energy isolation devices. NOT AS EMERGENCY STOP DEVICES.

WARNINGS:

Failure to follow these instructions can result in personal injury and/or property damage.

STANDARD WARRANTY

All products sold by the ROSS Group are warranted for a one-year period [with the exception of Filters, Regulators and Lubricators ("FRLs") which are warranted for a period of seven (7) years] from the date of purchase. All products are, during their respective warranty periods, warranted to be free of defects in material and workmanship. The ROSS Group's obligation under this warranty is limited to repair, replacement or refund of the purchase price paid for products which the ROSS Group has determined, in its sole discretion, are defective. All warranties become void if a product has been subject to misuse, misapplication, improper maintenance, modification or tampering. Products for which warranty protection is sought must be returned to the ROSS Group freight prepaid.

THE WARRANTY EXPRESSED ABOVE IS IN LIEU OF AND EXCLUSIVE OF ALL OTHER WARRANTIES AND THE ROSS GROUP EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES EITHER EXPRESSED OR IMPLIED WITH RESPECT TO MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THE ROSS GROUP MAKES NO WARRANTY WITH RESPECT TO ITS PRODUCTS MEETING THE PROVISIONS OF ANY GOVERNMENTAL OCCUPATIONAL SAFETY AND/OR HEALTH LAWS OR REGULATIONS. IN NO EVENT IS THE ROSS GROUP LIABLE TO PURCHASER, USER, THEIR EMPLOYEES OR OTHERS FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES WHICH MAY RESULT FROM A BREACH OF THE WARRANTY DESCRIBED ABOVE OR THE USE OR MISUSE OF THE PRODUCTS. NO STATEMENT OF ANY REPRESENTATIVE OR EMPLOYEE OF THE ROSS GROUP MAY EXTEND THE LIABILITY OF THE ROSS GROUP AS SET FORTH HEREIN.



	,			
Americas	ROSS CONTROLS	USA	Tel: +1-248-764-1800	www.rosscontrols.com
	ROSS CONTROLS CANADA Ltd.	Canada	Tel: +1-416-251-7677	www.rosscanada.com
	ROSS DO BRASIL EIRELI	Brazil	Tel: +55-11-4335-2200	www.rosscontrols.com.br
EUROPE	ROSS EUROPA GmbH	Germany	Tel: +49 (0)6103-7597-100	www.rosseuropa.com
	ROSS FRANCE SAS	France	Tel: +33-(0)1-49-45-65-65	www.rossfrance.com
	ROSS PNEUMATROL Ltd.	United Kingdom	Tel: +44 (0)1254 872277	www.rossuk.co.uk
Asia & Pacific	ROSS CONTROLS INDIA Pvt. Ltd.	India	Tel: +91-44-2624-9040	www.rosscontrolsindia.com
	ROSS CONTROLS (CHINA) Ltd.	China	Tel: +86-21-6915-7961	www.rosscontrolschina.com
	ROSS ASIA K.K.	Japan	Tel: +81-42-778-7251	www.rossasia.co.jp
	AUTOMATIC VALVE INDUSTRIAL LLC	USA	Tel: +1-248-474-6700	www.automaticvalve.com
	ROSS DECCO COMPANY	USA	Tel: +1-248-764-1800	www.rossdecco.com
	ROSS PNEUMATROL Ltd.	United Kingdom	Tel: +44 (0)1254 872277	www.pneumatrol.com
	manufactIS GmbH	Germany	Tel: +49 (0)2013-16843-0	www.manufactis.net

Full-Service Global Locations

There are ROSS Distributors Throughout the World

To meet your requirements across the globe, ROSS distributors are located throughout the world. Through ROSS or its distributors, guidance is available for the selection of ROSS products, both for those using fluid power components for the first time and those designing complex systems.

Other literature is available for engineering, maintenance, and service requirements.

If you need products or specifications not shown in this catalog, please visit ROSS' website, contact ROSS or your ROSS distributor. The ROSS Support Team will be happy to assist you in selecting the best product for your application.

For a current list of countries and local distributors, visit ROSS' at www.rosscontrols.com.