


# HAZARDOUS LOCATIONS DIRECTIONAL CONTROL VALVES 27 SERIES





# **Explosion-Proof Directional Control Valves 27 Series Product Overview**

#### **Explosion-Proof Safety Function**

Valves are equipped with explosion-proof coils for use in hazardous locations to prevent potentially explosive situations.



Illustration examples.

For use in hazardous locations to prevent potentially explosive situations. The 27 Series explosion-proof solenoid pilot controlled valves are ideal for applications in a wide range of industries and environments where safety from electrical ignition of flammable gases, vapors, flammable liquids, combustible dust, or easily ignitable fibers is a concern.

Applicable Requirements	C22.2 No. 0-10 - General Requirements - Canadian Electrical Code, Part II; CSA C22.2 No. 25-1966 - Enclosures for use in Class II Groups E, F and G Hazardous Locations; CSA C22.2 No. 142-M1987 - Process Control Equipment; C22.2 No. 213-M1987 - Nonincendive Electrical Equipment for Use in Class I, Division 2 Hazardous Locations; CAN/CSA E79-0-95 - Electrical apparatus for explosive atmospheres, Part 0: General requirements; CAN/CSA E79-18-95 - Electrical apparatus for explosive atmospheres, Part 18: Encapsulation "m".
APPROVED for use in the following Hazardous Locations	Ex m II T4 and Division 1 – Specifications in accordance to CSA certificate: Class I, Division 1, Groups A, B, C and D; Class II, Groups E, F and G; Class III; Class I, Division 2, Groups A, B, C, D
Specifications in accordance to FM certificate	Explosion-proof Class I, Division 1, Groups A, B, C, D, T4, Ta = 60 °C (encapsulation/explosion-proof Class I, Zone 1, AEx m II T4, Ta = 60 °C; dust-ignition-proof for Class II/III, Division 1, Groups E, F and G, T4, Ta = 60 °C); Nonincendive Class I, Division 2, Groups A, B, C, D, T4, Ta = 60 °C; Suitable for Class II, III, Division 2, Groups E, F, G, T4, Ta = 60 °C CSA CLASS 2258 02 – process control equipment – for hazardous locations FM CLASS 3600, 3611, 3615, 3810 – hazardous (classified) location electrical equipment

VALVE FEATURES					
Poppet Design	Poppet construction for high dirt tolerance				
High Velocity	Near zero leakage				
Positive Sealing	No sliding action to prevent damage and wear				
Explosion-proof Coils	Contain any spark originating from within the coil or housing preventing the ignition of any flammable material in the surrounding environment, resulting in a larger explosion				
Flexible Pilot	Pilot can rotate, giving the ability to change orientation				


# **Specifications**




		STANDARD	<b>SPECIFICATIONS</b>			
	Function		2/2, 3/2, and 4/2	Valve		
	Construction Design		Poppet	Poppet		
	Actuation		Electrical - Soleno	oid Pilot Controlled		
GENERAL	Mounting	Туре	Inline			
	Mounting	Orientation	Vertically with pil	ot solenoids on top		
	Connection		Threaded; G, NP	Т		
	Minimum Operation Fred	quency	Once per month,	to ensure proper function		
		Ambient	40° to 140°F (4°	to 60°C)		
	Temperature	Media	40° to 175°F (4°	to 80°C)		
OPERATING	Flow Media		Filtered air			
CONDITIONS	O a sulling Bases as	Body Size 3/8 & 1-1/2	15 to 150 psig (1	to 10 bar)		
	Operating Pressure	Body Size 2	30 to 150 psig (2	.1 to 10 bar)		
	External Pilot Supply		Must be equal to	Must be equal to or greater than inlet pressure		
		Operating Pr	ressure	Power Consumption (each solenoid)		
	Solenoids	24 volts DC		4.6 watts		
ELECTRICAL Data		120 volts AC, 60 Hz		6.8 VA		
DAIA		Rated for continuous duty				
	Enclosure Rating		IP65, IEC 60529	IP65, IEC 60529		
	Electrical Connection		Three lead wires	Three lead wires with 1/2" NPT conduit connection		
	Valve Body		Cast Aluminum			
CONSTRUCTION MATERIAL	Poppet		Acetal and Stainle	Acetal and Stainless Steel		
	Seals		Buna-N	Buna-N		
SAFETY DATA	Safety Integrity Level (SIL)		integrity level 2 (S diagnosis) in singu	heinland in accordance to IEC 61508 and IEC 61511 safety IL 2) and EN ISO 13849-1, PL c (with application specific ular application with HFT = 0 and SIL 3 and PL e in redundant FT≥1, for details see certificate.		

PRODUCT CREDENTIALS							
Safety Category	ATEX Certified	Factory Mutual Certification	Declaration ( CE	of Conformity EAC	CSA Certificate of Compliance	Canadian Registration Number (CRN)	
Cat 1	<b>€x</b>	FM APPROVED	C€	ERC	© o us	Available for appropriately tested valves	

# **Ordering Information**




	Port Size	Flo	w C <sub>V</sub>	
Body Size	1.0	Normally Closed	Normally Open	Weight Ib (kg)
	1, 2	1-2	1-2	
	1/4	2.3	2.3	
3/8	3/8	3.8	3.3	3.0 (1.4)
	1/2	4	3.5	
	1/2	7.7	6.5	
3/4	3/4	9.0	7.3	3.6 (1.6)
	1	9.0	7.9	
	1	24	21	
1-1/4	1-1/4	29	20	7.5 (3.4)
	1-1/2	29	21	
	1-1/2	49	49	
2	2	57	57	16.0 (7.3)
	2-1/2	64	72	




# **Ordering Information**







	Port	Port Size		Flo	Waiala		
Body Size	1010			Normally Closed		lly Open	Weight Ib (kg)
	1, 2	3	1-2	2-3	1-2	2-3	, , ,
	1/4	1/2	2.5	3.1	2.3	2.7	
3/8	3/8	1/2	3.6	5.3	2.8	3.2	2.5 (1.2)
	1/2	1/2	3.3	5.3	2.8	3.2	
	1/2	1	6.3	9.2	6.3	8.0	
3/4	3/4	1	7.7	11	6.9	7.4	3.3 (1.5)
	1	1	8.0	12	6.8	7.5	
	1	1-1/2	23	34	17	24	
1-1/4	1-1/4	1-1/2	30	32	19	24	7.0 (3.2)
	1-1/2	1-1/2	30	31	19	23	
	1-1/2	2-1/2	68	70	57	59	
2	2	2-1/2	70	70	58	61	16.5 (7.4)
	2-1/2	2-1/2	70	71	54	55	



# **Ordering Information**




Body Size	Port Size		Flov	w C <sub>V</sub>	Weight
Dody Olzo	1, 2, 4	3	1-2, 1-4	4-3, 2-3	lb (kg)
	1/4	1/2	2.1	2.9	
3/8	3/8	1/2	2.9	4.2	1.9 (0.9)
	1/2	1/2	3.1	4.3	
	1/2	1	5.6	8.1	
3/4	3/4	1	7.0	9.3	4.2 (1.9)
	1	1	7.8	10	
	1	1-1/2	19	26	
1-1/4	1-1/4	1-1/2	21	27	11.0 (5.0)
	1-1/2	1-1/2	22	27	



# **Valve Technical Data**




# 2/2 Valves



# **Valve Technical Data**


### 3/2 Valves



# **Valve Technical Data**



### 4/2 Valves



For additional information, and to assist you with piping and connectivity designs, our products are available in downloadable 2D drawings and 3D CAD models in a wide range of options including native formats, visit www.rosscontrols.com.

# **Accessories**

# **EXHAUST SILENCERS**

Silencers	Port Size	Thread Type	Model Nu	mber	<b>Flow</b> Avg. C <sub>v</sub>	Pressure Range psig (bar)
			R/Rp Thread	NPT Thread		
	1/2	Male	D5500A4003	5500A4003	4.7	0-290 (0-20) maximum
	1	Male	D5500A6003	5500A6003	15	
	1-1/2	Female	D5500A8001	5500A8001	30	
	2-1/2	Female	D5500A9002	5500A9002	104	

### **FEMALE SILENCER CONNECTORS**

	Material	Fitting Pipe Size	Thread Type	Model Number		
Hex Nipples	- material			BSPT Thread	NPT Thread	
пох піррісэ	Steel	1-1/2	Male - Male	122J39	488J27	
	Stainless Steel	2-1/2	Male - Male	123J39	490J27	

### **SOLENOID PILOT CONVERSION KITS**

Description	Valve Body Size	Kit Number
ROSS Controls standard poppet solenoid pilot controlled valves for line mounting can be easily field-converted into an explosion-proof solenoid pilot poppet valve. Listed on the right are the conversion kit numbers to replace the obsolete ROSS	1/4" - 1" (C <sub>v</sub> up to 10)	2370K77W
explosion proof pilot, or to convert a standard inline valve to an explosion-proof valve.	1" (C <sub>v</sub> up to 29) - 2-1/2"	2371K77W

# **CAUTIONS, WARNINGS And STANDARD WARRANTY**



ROSS OPERATING VALVE, ROSS CONTROLS®, ROSS DECCO®, and AUTOMATIC VALVE INDUSTRIAL, collectively the "ROSS Group".

#### PRE-INSTALLATION or SERVICE

- 1. Before servicing a valve or other pneumatic component, be sure all sources of energy are turned off, the entire pneumatic system is shut down and exhausted, and all power sources are locked out (ref: OSHA 1910.147, EN 1037).
- 2. All ROSS Group Products, including service kits and parts, should be installed and/or serviced only by persons having training and experience with pneumatic equipment. Because any product can be tampered with and/or need servicing after installation, persons responsible for the safety of others or the care of equipment must check ROSS Group Products on a regular basis and perform all necessary maintenance to ensure safe operating conditions.
- 3. All applicable instructions should be read and complied with before using any fluid power system to prevent harm to persons or equipment. In addition, overhauled or serviced valves must be functionally tested prior to installation and use. If you have any questions, call your nearest ROSS Group location.
- 4. Each ROSS Group Product should be used within its specification limits. In addition, use only ROSS Group components to repair ROSS Group Products.

#### WARNINGS

Failure to follow these instructions can result in personal injury and/or property damage.

#### FILTRATION and LUBRICATION

- 1. Dirt, scale, moisture, etc., are present in virtually every air system. Although some valves are more tolerant of these contaminants than others, best performance will be realized if a filter is installed to clean the air supply, thus preventing contaminants from interfering with the proper performance of the equipment. The ROSS Group recommends a filter with a 5-micron rating for normal applications.
- 2. All standard ROSS Group filters and lubricators with polycarbonate plastic bowls are designed for compressed air applications only. Use the metal bowl guard, where provided, to minimize danger from high pressure fragmentation in the event of bowl failure. Do not expose these products to certain fluids, such as alcohol or liquefied petroleum gas, as they can cause bowls to rupture, creating a combustible condition and hazardous leakage. Immediately replace crazed, cracked, or deteriorated bowls.
- 3. Only use lubricants which are compatible with materials used in the valves and other components in the system. Normally, compatible lubricants are petroleum base oils with oxidation inhibitors, an aniline point between 180°F (82°C) and 220°F (104°C), and an ISO 32, or lighter, viscosity. Avoid oils with

phosphate type additives which can harm polyurethane components, potentially leading to valve failure which risks personal injury, and/or damage to property.

#### **WARNINGS:**

Failure to follow these instructions can result in personal injury and/or property damage.

#### **AVOID INTAKE/EXHAUST RESTRICTION**

- 1. Do not restrict air flow in the supply line. To do so could reduce the pressure of the supply air below minimum requirements for the valve and thereby causing erratic action.
- 2. Do not restrict a valve's exhaust port as this can adversely affect its operation. Exhaust silencers must be resistant to clogging and must have flow capacities at least as great as the exhaust capacities of the valves. Contamination of the silencer can result in reduced flow and increased back pressure.

WARNINGS: Failure to follow these instructions can result in personal injury and/or property damage.

#### SAFETY APPLICATIONS

- 1. Mechanical Power Presses and other potentially hazardous machinery using a pneumatically controlled clutch and brake mechanism must use a press control double valve with a monitoring device. A double valve without a self-contained monitoring device should be used only in conjunction with a control system which assures monitoring of the valve. All double valve installations involving hazardous applications should incorporate a monitoring system which inhibits further operation of the valve and machine in the event of a failure within the valve mechanism.
- 2. Safe Exhaust (dump) valves without a self-contained monitoring device should be used only in conjunction with a control system which assures monitoring of the valve. All Safe Exhaust valve installations should incorporate a monitoring system which inhibits further operation of the valve and machine in the event of a failure within the valve mechanism.
- 3. Per specifications and regulations, the ROSS L-0-X $^{\odot}$  and L-0-X $^{\odot}$  with EEZ-0N $^{\odot}$ , N06 and N16 Series operation products are defined as energy isolation devices, NOT AS EMERGENCY STOP DEVICES.

#### **WARNINGS:**

Failure to follow these instructions can result in personal injury and/or property damage.

#### STANDARD WARRANTY

All products sold by the ROSS Group are warranted for a one-year period [with the exception of Filters, Regulators and Lubricators ("FRLs") which are warranted for a period of seven (7) years] from the date of purchase. All products are, during their respective warranty periods, warranted to be free of defects in material and workmanship. The ROSS Group's obligation under this warranty is limited to repair, replacement or refund of the purchase price paid for products which the ROSS Group has determined, in its sole discretion, are defective. All warranties become void if a product has been subject to misuse, misapplication, improper maintenance, modification or tampering. Products for which warranty protection is sought must be returned to the ROSS Group freight prepaid.

THE WARRANTY EXPRESSED ABOVE IS IN LIEU OF AND EXCLUSIVE OF ALL OTHER WARRANTIES AND THE ROSS GROUP EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES EITHER EXPRESSED OR IMPLIED WITH RESPECT TO MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THE ROSS GROUP MAKES NO WARRANTY WITH RESPECT TO ITS PRODUCTS MEETING THE PROVISIONS OF ANY GOVERNMENTAL OCCUPATIONAL SAFETY AND/OR HEALTH LAWS OR REGULATIONS. IN NO EVENT IS THE ROSS GROUP LIABLE TO PURCHASER, USER, THEIR EMPLOYEES OR OTHERS FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES WHICH MAY RESULT FROM A BREACH OF THE WARRANTY DESCRIBED ABOVE OR THE USE OR MISUSE OF THE PRODUCTS. NO STATEMENT OF ANY REPRESENTATIVE OR EMPLOYEE OF THE ROSS GROUP MAY EXTEND THE LIABILITY OF THE ROSS GROUP AS SET FORTH HEREIN.



	,			
	ROSS CONTROLS	USA	Tel: +1-248-764-1800	www.rosscontrols.com
AMERICAS	ROSS CONTROLS CANADA Ltd.	Canada	Tel: +1-416-251-7677	www.rosscanada.com
	ROSS DO BRASIL EIRELI	Brazil	Tel: +55-11-4335-2200	www.rosscontrols.com.br
	ROSS EUROPA GmbH	Germany	Tel: +49 (0)6103-7597-100	www.rosseuropa.com
EUROPE	ROSS FRANCE SAS	France	Tel: +33-(0)1-49-45-65-65	www.rossfrance.com
	ROSS PNEUMATROL Ltd.	United Kingdom	Tel: +44 (0)1254 872277	www.rossuk.co.uk
	ROSS CONTROLS INDIA Pvt. Ltd.	India	Tel: +91-44-2624-9040	www.rosscontrolsindia.com
ASIA & PACIFIC	ROSS CONTROLS (CHINA) Ltd.	China	Tel: +86-21-6915-7961	www.rosscontrolschina.com
	ROSS ASIA K.K.	Japan	Tel: +81-42-778-7251	www.rossasia.co.jp
	AUTOMATIC VALVE INDUSTRIAL LLC	USA	Tel: +1-248-474-6700	www.automaticvalve.com
	ROSS DECCO COMPANY	USA	Tel: +1-248-764-1800	www.rossdecco.com
	ROSS PNEUMATROL Ltd.	United Kingdom	Tel: +44 (0)1254 872277	www.pneumatrol.com
	manufactIS GmbH	Germany	Tel: +49 (0)2013-16843-0	www.manufactis.net

# Full-Service Global Locations

There are ROSS Distributors Throughout the World

To meet your requirements across the globe, ROSS distributors are located throughout the world. Through ROSS or its distributors, guidance is available for the selection of ROSS products, both for those using fluid power components for the first time and those designing complex systems.

Other literature is available for engineering, maintenance, and service requirements.

If you need products or specifications not shown in this catalog, please visit ROSS' website, contact ROSS or your ROSS distributor. The ROSS Support Team will be happy to assist you in selecting the best product for your application.

For a current list of countries and local distributors, visit ROSS' at www.rosscontrols.com.