
## Type BR Loadcenters and Circuit Breakers

## **Type BR Loadcenter**




# Warranty

10-year warranty on all Type BR loadcenters and circuit breakers.


1

## **Catalog Number Selection**

## Single-Phase Plug-on Neutral Loadcenters



# Single- and Three-Phase Legacy Loadcenters



### Note

① No character space used.

# Type BR Loadcenters and Circuit Breakers

## Single-Phase—Main Lug Loadcenters—Small Space

## Single-Phase Three-Wire - 120/240 Vac - Insulated/Bondable Split Neutral

		Main Ampere Rating	Maximum 1-Inch (25 Spaces		Enclosure Type	Trim Type	Box Size	Wire Size Range Cu/Al 60 °C or 75 °C for Main Lugs	Loadcenter Catalog Number
<u> </u>	0.41	70	2	4	Indoor	Surface (no door)	5	#8-#2	BR24L70SP ©2
Surface	Outdoor		2	4	Indoor	Surface (no door)	5		BR24L70SGP 23
	E.		2	4	Outdoor	_	5R	#14–1/0	BR24L70RP 124
			2	4	Indoor	Flush (no door)	5		BR24L70FP 1)2
			2	4	Indoor	Flush (no door)	5		BR24L70FGP 26
		125	2	4	Indoor	Surface (no door)	6		BR24L125SP 112
Flush	Outdoor	,	2	4	Outdoor	_	6R		BR24L125RP 124
			2	4	Outdoor	_	6R		BR24L125RSEP 278
			2	4	Outdoor	_	6R	<del></del>	BR24L125RSE2P 267
			2	4	Indoor	Flush (no door)	6	<del></del>	BR24L125FP 102
			4	8	Indoor	Surface (no door)	7	#14-1/0	BR48L125SP 109
10			4	8	Indoor	Surface (no door)	7		BR48L125SGP 39
Surface	(No Door)		4	8	Outdoor	_	7R		BR48L125RP 149
Walter Street Street			4	8	Indoor	Flush (no door)	7	<del></del>	BR48L125FP 109
			4	8	Indoor	Flush (with door)	7		BR48L125FDP 109
			4	8	Indoor	Flush (no door)	7		BR48L125FGP 3 9
			6	12	Indoor	Surface (no door)	7	#14-#1	BR612L125SP 1100
-			6	12	Indoor	Surface (no door)	7	<del>_</del>	BR612L125SGP @®
Flush (No Door)			6	12	Indoor	Surface (with door)	7		BR612L125SDP 100
			6	12	Indoor	Surface (with door)	7		BR612L125SDGP @@
1			6	12	Outdoor	_	7R		BR612L125RP 1410
	.0		6	12	Indoor	Flush (no door)	7		BR612L125FP 100
E			6	12	Indoor	Flush (no door)	7		BR612L125FGP ©®®
Outdoor			6	12	Indoor	Flush (with door)	7		BR612L125FDP <sup>(1)</sup>
Vuluoor			6	12	Indoor	Flush (with door)	7		BR612L125FDGP ©®®
			8	16	Indoor	Surface (no door)	7	#14-#1	BR816L125SP 100
			8	16	Indoor	Surface (no door)	7		BR816L125SGP @@
			8	16	Indoor	Surface (with door)	7		BR816L125SDP 100
			8	16	Indoor	Surface (with door)	7		BR816L125SDGP ®®
			8	16	Outdoor	_	7R		BR816L125RP 14®
			8	16	Indoor	Flush (no door)	7	<u></u>	BR816L125FP 100
			8	16	Indoor	Flush (no door)	7		BR816L125FGP 5000
			8	16	Indoor	Flush (with door)	7		BR816L125FDP 100
			8	16	Indoor	Flush (with door)	7		BR816L125FDGP 6000

- ① Ground bar kits priced separately. See Page V1-T1-71.
  - For 2/4 circuit loadcenters, use GBK5 or GBK520 ground bar.
  - For 4/8, 6/12 and 8/16 circuit loadcenters, use GBK10 ground bar.
  - Ground bars mount to the left side wall of the enclosure for the 4/8, 6/12 and 8/16 circuit loadcenters.
- $\@ifnextchar[{\@model{2}}{@}$  Suitable for use as service equipment when not more than two service disconnecting mains are provided or when not used as a lighting and appliance panelboard.
- <sup>③</sup> Ground bar GBK5 is installed.
- @ Rainproof panels are furnished with hub closure plates. For rainproof hubs, refer to Page V1-T1-71.
- © CSA and UL approved.
- ® Neutral/ground holes (6) #14–6 and (3) #14–2/0 AWG Cu/AI.
- $\ensuremath{\mathfrak{D}}$  For use as service entrance applications only.
- ® Neutral/ground holes (6) #14–6 and (3) #14–1/0 AWG Cu/AI.
- 9 Suitable for use as service equipment when not more than two service disconnecting mains are provided or when not more than six service disconnecting mains are provided and when not used as a lighting and appliance panelboard.
- Suitable for use as service equipment when a main breaker is used or when not more than six service disconnecting mains are provided and when not used as a lighting and appliance panelboard.
- (1) Ground bar GBK10 is installed.
- @ Ground bar GBK14 is installed.

Box sizes Pages V1-T1-77 through V1-T1-81.