# Tools and accessories for crimp contacts

 CX 6/12 \*
 (40A)
 197

 CX 5/36 \*
 (40A)
 198

 CX 12/2 \*
 (40A)
 199

 MIXO
 (40A)
 267 - 272

\* the underlined polarities indicate those contacts that require the tools shown in this page

manual crimping tool
positioner - gauge



removal tool



description	part No.	part No.
crimping tool for <b>40A</b> DANIELS M309 model (turret excluded)	CXPZ D	
positioner (see note) for contacts <b>40A</b> ( <b>CX</b> and <b>RX HNM</b> series)	CXTP 40	
"go / no go" control gauge to verify indenter closure (see note)	CXPNP	
removal tool for the extraction of contacts from the inserts for 40A contacts		CXES

#### Notes:


#### Positioner

 An interchangeable and indispensable accessory of the CXPZ D crimping tool, it precisely positions the contact where crimping is performed.

## "go / no go" control gauge

 A tool used to periodically check that the crimping tool meets standard requirements.

# CXPNP



## CXPZ D



# CXTP 40



## CXTP 40

CONTACT	CXMA/CXFA	1.5	2.5	4.0	6.0	10
WIRE SIZE	mm²	1,5	2,5	4	6	10
	AWG	16	14	12	10	8
SEL. NO.		5	5	5	7	8
USE WITH -						
USE WITH			ĒΡ			